


edishinē

Floor Lamp

[Instruction Manual]











Please pay attention to the warning signs
Read the instructions with caution before operating
and keep it properly

CAUTION


1. Before assembly, place all parts out on a clean flat surface and inspect each part for defects that may have occurred during shipping.
2. Inspect wire insulation for any cuts, abrasions or exposed copper that may have resulted during shipping. If there are any defects in the wire, DO NOT continue assembly. Please send an email to our Customer Service immediately.
3. Consult a qualified electrician if you have any electrical questions.
4. Never drape clothes over the lamp.
5. To reduce the likelihood of tipping over, we recommend placing the lamp behind furniture and keep children and pets away.
6. To prevent children from suffocating and choking, keep them away from packing materials.
7. Please keep this manual and hand it over when you transfer the product.

Packing List:

Part Number	Part Drawing	Part Describe	Quantity
①		Lampshade	1
②		Lamp Body (4 Metal Elbow Tubes)	1

Part Number	Part Drawing	Part Describe	Quantity
③		Base	1
④		Bulb & Remote Control	1
⑤		accessories-aa Screwdriver	1
		accessories-bb Screws	7
		accessories-cc Wrench	1
		accessories-dd Socket Ring	1

Note: Parts ⑤ (aa, bb, cc and dd) are enclosed in the sealed bag.



INSTALLATION INSTRUCTIONS

STEP 01: INSTALL LAMP BODY

- Insert Elbow Tube (A→B→C→D). then tighten Screw (bb) using Screwdriver (aa).
- Screw Elbow Tube (D) into the threaded adapter on the base (E).

STEP 02: ADJUST & SECURE BASE

- Use Wrench (cc) to adjust the lock nut at the bottom of the base (E). Position the lamp body correctly, then tighten the nut securely.

STEP 03: INSTALL LAMP SHADE & HEAD

- Place the lampshade (F) onto the lamp head and secure it tightly using the Socket Ring (dd).
- Install the bulb (G).


STEP 04: FINAL OPERATION

- Plug in the power cord and turn on the lamp by pressing the Foot Switch(H) on the cord.

Remote control bulb instructions for use

1. Install the bulb to the floor lamp, and insert the batteries into the remote control.
2. Depress the foot switch gently to turn on the floor lamp.
3. Control the bulb with remote control.

NOTE: To control the bulb by remote control, you must plug the floor lamp into the power supply first, then keep the foot switch in the ON state by depressing it gently.



Note.CODE MATCHING

If the remote control is not functioning, follow these steps:

- 1.Ensure the remote is powered by 2 AAA batteries(1.5V).
- 2.Disconnect the power supply to the bulb for about 10 seconds and then back on.
3. Within 10seconds press and hold the power button "(" until the light flashes and the pairing is successful.

- 1 Auto-off after 1H:**
The bulb flashes once after pressing it, indicating enter the 1-Hour Timer mode; if switch it on/off with foot switch, plug or remote control during the timing period, it will automatically exit the timing function.
- 2 ON/OFF:**
Turn the bulb ON/OFF.
- 3 Brightness +:**
Press the button to increase the brightness, 5 levels in total.
- 4 Brightness -:**
Press the button to decrease the brightness, 5 levels in total.
- 5 Color temperature +:**
Press the button to increase the color temperature, 5 levels in total.
- 6 Color temperature -:**
Press the button to decrease the color temperature, 5 levels in total.
- 7 Max Brightness Button:**
No matter which color temperature is set, press this button once to adjust the brightness to 100% at this color temperature.
- 8 3 color temperature modes:**
Press the button to cycle through the 3 common color temperature modes.
- 9 Night Light Mode:**
Press the button to enter Night Light Mode.
- 10 Breastfeed Mode:**
Press the button to enter Breastfeed Mode.
- 11 Office Mode:**
Press the button to enter Office Mode.
- 12 Reading Mode:**
Press the button to enter Reading Mode.

Specifications

- Input Voltage: 120VAC 60Hz
- Socket Type: Standard Medium E26
- Max.load Power: Incandescent Bulb 60W or LED Bulb 12W

One Year Limited Warranty

Supported by our professional R&D team and QC team, we provide One Year Warranty for materials and workmanship from the purchase date. Please note that the warranty does not cover damage caused by personal misuse or improper installation. Please attach your Order ID and Name so that our dedicated customerservice team can help you better.