




OUTDOOR BILLIARD TABLE

7 FT/84 INCH/213.5 CM



ASSEMBLY INSTRUCTIONS

Model: BT-8004



CONTACT INFO

Distributed by Airzone LLC.

Questions or Comments? Call **1-800-775-6524** or Mail **CustomerService@airzone-na.com**

Made in China.

Two or more adults required for assembly

IMPORTANT

After receiving the shipment, inspect the product thoroughly to ensure that it has been shipped with care.

Before assembly make sure that the packaging contains all parts.

For service or parts replacement under warranty, the official sales receipt is required. Please keep your official sales receipt for future reference

OFFICIAL SALES RECEIPT CAN BE ATTACHED HERE

Service or parts under warranty
only available with show of receipt

Please contact us for any questions at **1-800-775-6524** before returning this product.

Please inspect your play field before assembling this product. It is not possible to replace or repair the play field under warranty. Therefore, if the play field is damaged, the complete table needs to be returned to the place of purchase to be exchanged for a new table

Use a soft, clean and level surface to begin the assembly of your game table. (Such as the inside of the cardboard box, carpet, etc.). This will prevent the table surface from getting damaged. Make sure to remove any staples from the cardboard box before using it as an underground.

This game table will be partially assembled upside down and then turned over onto its legs. This is a heavy game and turning it over will require at least two strong adults.

When installing parts that have more than one screw or bolt, hand tighten all screws or bolts in place before tightening with screwdriver or allen key.

Electric screwdrivers may be helpful during assembly. However, please set a low torque and use extreme caution because screws may be stripped or over tightened if the electric screwdriver's torque is set too high.

Save these IMPORTANT Safety Instructions

Warning:

This product is intended for outdoor use. If the product is not in use it is recommended to protect the table with the supplied cover to prevent dirt from accumulating on the play surface.

This table should only be used by adults or under the supervision of adults. This table is NOT a toy.

Do not sit, climb, or lean on the table. Do not place anything, including people, on the top of the play field.

Do not drag the table when moving it, as this could damage the legs or unit beyond repair.

Do not place any food or drinks on the pool and Table tennis table.

Only use the table for its intended purpose

Damaged or worn parts may be dangerous for users and the integrity of the table. Replace worn or damaged components immediately and do not use the table until any issues have been resolved.

Unauthorized repairs or changing the table's design or functions may be dangerous and will void the warranty.

Check all screws, bolts, etc. with regular intervals to ensure that they are in good working condition and have not loosened overtime.

Care and Maintenance

Pool tables are a long term investment that will last many years if you maintain them well. The felt on the pool table is delicate and must be cleaned with caution. Only use brushes that are made for pool tables and never scrub in a circular pattern. Vacuum dust off of the table after you brush it. Dab at spills immediately but never rub them. Only use pool table approved cleaners. Keep your table clean by not chalking over it, keeping it covered, and keeping anything that's not pool equipment off of it.

Turning the table

It will take minimum **TWO STRONG ADULTS** to lift the assembled table from the floor and turn it over without putting weight on the legs.




Table may become damaged if it is placed to the floor in an angle.

TOOLS

Required

Phillips head screwdriver
(Not included)

Allen key
(included)

Recommended

Electric screwdriver


Socket wrench set

Level

PARTS IDENTIFIER


How to use

To assure a smooth assembly we recommend to ensure yourself that you have received all parts listed and in the correct quantities.



PARTS IDENTIFIER


1



x1

STEP 1Billiard Cabinet


2



x4

STEP 1Leg

3




x4

STEP 2Leg Leveler

Hardware


60



x16

STEP 1Bolt


61



x16

STEP 1Washer

62




x1

STEP 1Allen Key

Accessories


90



x1

Brush


91



x2

Cue Chalk


92



x1

Rack


93



x1

Pool Balls


94



x2

Cues

95



x1

Dirt Cover


ASSEMBLY INSTRUCTIONS

Before assembly make sure that all parts are available and sorted

All parts can be identified on the parts and accessories identifier

Please inspect your play field before assembling this product. It is not possible to replace or repair the play field under warranty. Therefore, if the play field is damaged, the complete table needs to be returned to the place of purchase to be exchanged for a new table


STEP 1



COMPONENTS	Q.TY	HARDWARE	Q.TY
1 Billiard cabinet	x1	60 Bolt	x16
2 Leg	x4	61 Washer	x16
		62 Allen Key	x1

NOTE

STEP 2




COMPONENTS	Q.TY	HARDWARE	Q.TY
3 Leg Leveler	x4		

NOTE

ASSEMBLY INSTRUCTIONS

STEP 3



COMPONENTS	Q.TY	HARDWARE	Q.TY
95 Dirt Cover	x1		
NOTE			

Limited Warranty

This product is warranted to the original owner to be free from defects in workmanship and materials when used for the intended purpose under normal use and conditions for a period of 90 days from the date of original retail purchase. Proof of purchase is required when requesting for parts or service.

This Limited Warranty covers all defects in materials and workmanship but will be void if the product is:

- Damaged due to transportation, improper usage, storage, negligence, misuse, abuse, acts of nature or accidents (including for not following the instructions supplied with this product).
- Used in a commercial environment such as schools, correctional facilities, recreational centers, camps, churches, day-cares or any other public facility and/or as rentals.
- Modified or repaired by unauthorized persons.

This Limited Warranty does not cover:

- Nonessential items such as accessories, cosmetic parts and any other items showing wear due to normal usage.
- Any transportation, delivery, installation costs incurred by the consumer from original place of purchase to home, or back to the original place of purchase.
- Items purchased from a third party or from an unauthorized retailer.

This warranty is nontransferable and is expressly limited to the repair or replacement of the defective product. During the warranty period, the manufacturer shall repair or replace defective parts at no cost to the purchaser. Shipping charges and insurance are not covered and are the responsibility of the purchaser. Labor charges and related expenses for removal, installation or replacement of the product or components are not covered under this warranty.

The manufacturer reserves the right to make substitutions to warranty claims if parts are unavailable or obsolete.

Distributed by Airzone LLC.

Questions, Comments or Warranty Claims:
CALL 1-800-775-6524

or

MAIL CustomerService@airzone-na.com