


# TV STAND

Assembly Instructions - Please keep for future reference



## Dimensions

Width-66.93inch

Depth-15.75inch

Height-17.72inch

Important - Please read these instructions fully before starting assembly



## Safety and Care Advice

**Important – Please read these instructions fully before starting assembly**

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



power drill is set on a low torque setting.

- To reduce the likelihood of damaging your product please ensure that your

### Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

### Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightened properly.

**WARNING**  
**In order to help prevent overturning –**  
**please follow these instructions**






To help prevent product toppling over please follow the below steps:-

Use the anti tip strap or wall fixing method provided (if applicable)  
Do not allow children to climb or hang on the furniture  
Do not open more than one drawer at a time  
Do not place heavy items in the top drawers  
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose


# Components-Fittings

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

|                                                                                                                            |                                                                                                                               |                                                                                                                               |                                                                                                                              |
|----------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------|
| <p>(A)</p>  <p>6*35mm Cam Bolt x 10+2</p> | <p>(B)</p>  <p>15*10mm Cam Lock x 10+2</p>   | <p>(C)</p>  <p>8*30mm Dowel x 26+2</p>      | <p>(D)</p>  <p>4*40mm Screw x 10+2</p>    |
| <p>(E)</p>  <p>3.5*14mm Screw x 32+2</p>  | <p>(F)</p>  <p>Metal handle x 4</p>          | <p>(G)</p>  <p>Phillips screwdriver x 1</p> | <p>(H)</p>  <p>3*12mm Screw x 16+2</p>    |
| <p>(I)</p>  <p>35*25*5mm EVA x 8</p>      | <p>(J)</p>  <p>Back plate buckle x 16+2</p> | <p>(K)</p>  <p>Shelf bracket x 16+2</p>      | <p>(L)</p>  <p>Allen key x 1</p>          |
| <p>(M)</p>  <p>M6*55mm Screw x 10+2</p> | <p>(N)</p>  <p>Paraffin x 1</p>            | <p>(O)</p>  <p>Hinge x 4</p>              | <p>(P)</p>  <p>Hole to stick x 10+2</p> |

Tools required



Phillips screwdriver or  
flat-head screwdriver


# Using Camlocks

## Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.  
NE PAS SERRER EXCESSIVEMENT.



## Step 2

Push the male camlock into the entry hole.

2




## Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




## Step 4

Turn the female camlock clockwise with a screwdriver.


You should feel a click when the camlock is locked in place.












The joint is now secure.

4



# Assembly Instructions





|                                                                                                              |                                                                                                              |                                                                                                               |                                                                                                               |
|--------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|
| <br>1700*400*15mm<br>① X1 | <br>1700*400*15mm<br>② X1 | <br>370*336*15mm<br>③ X1   | <br>370*336*15mm<br>④ X1 |
| <br>370*359*15mm<br>⑤ X1  | <br>370*359*15mm<br>⑥ X1  | <br>370*336*15mm<br>⑦ X1   | <br>320*294*12mm<br>⑧ X4 |
| <br>936*379*12mm<br>⑨ X2  | <br>364*299*21mm<br>⑩ X2  | <br>1610*310*50mm<br>⑪ X1 | <br>379*306*3mm<br>⑫ X2  |
| <br>379*306*3mm<br>⑬ X2   |                                                                                                              |                                                                                                               |                                                                                                               |



# Assembly Instructions

## Step 1

Please wipe paraffin N back and forth at the grooves of Part 1 and Part 2 to make the grooves smoothly




## Step 2



# Assembly Instructions

## Step 3







## Step 4

Step 1

Step 2

Step 3



(B)





15\*10mm Cam lock x 10

(P)




Hole to stick x 10



7

# Assembly Instructions

## Step 5




C




8\*30mm Dowel x 10

## Step 6




D



4\*40mm Screw x 10

# Assembly Instructions

## Step 7




C




8\*30mm Dowel x 6

## Step 8



L



Allen key x 1


M



M6\*55mm Screw x 10


# Assembly Instructions

## Step 9



|                                                                                                            |                                                                                                               |                                                                                                          |
|------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|
| <br>3.5*14mm Screw x 16 | <br>Back plate buckle x 16 | <br>35*25*5mm EVA x 8 |
|------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|


## Step 10




|                                                                                                           |
|-----------------------------------------------------------------------------------------------------------|
| <br>Shelf bracket x 16 |
|-----------------------------------------------------------------------------------------------------------|


# Assembly Instructions

## Step 11




## Step 12



|                                                                                                         |                                                                                                         |
|---------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------|
| <br>3*12mm Screw x 4 | <br>Metal handle x 2 |
|---------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------|


# Assembly Instructions

## Step 13



When the Part 9 is pushed into, it should be aligned with the upper and lower slots, with the drawing surface facing outward.


## Step 14





When the Part 9 is pushed into, it should be aligned with the upper and lower slots, with the drawing surface facing outward.


# Assembly Instructions

## Step 15




|                                                                                                                      |                                                                                                                       |                                                                                                               |
|----------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|
| <p>Ⓕ</p>  <p>Metal handle x 2</p> | <p>Ⓗ</p>  <p>3*12mm Screw x 12</p> | <p>⓪</p>  <p>Hinge x 4</p> |
|----------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|




## Step 16



If the door can't close, please adjust the hinges.



This is used to adjust the door panel in the up and down direction.




This is used to adjust the door panel in the front and back direction: Loosen the screw first, and then tighten screw after adjusting the door panel to the proper position.


|                                                                                                                        |
|------------------------------------------------------------------------------------------------------------------------|
| <p>Ⓔ</p>  <p>3.5*14mm Screw x 8</p> |
|------------------------------------------------------------------------------------------------------------------------|

# Assembly Instructions




## Step 17



If the door can't close, please adjust the hinges.



This is used to adjust the door panel in the up and down direction.



This is used to adjust the door panel in the front and back direction: Loosen the screw first, and then tighten screw after adjusting the door panel to the proper position.

Ⓔ



3.5\*14mm Screw x 8

## FINISH

