


Lavatory Faucet . SPARE PARTS

Satin Nickel

Oil Rubbed Bronze



No.	Name
1	Handle
2	Handle Seat
3	Set Screw
	Screw
	Connect
	Inverter
	Ring
4	Bonnet
5	Cartridge H
	Cartridge C
6	White Washer
7	Spout
8	Washer
	Aerator Insert
	Aerator Shell
9	O-Ring
10	Ring
11	Spout Seat
12	Escutcheon
13	Plate
14	Body
15	Screw
16	Base Plate
17	Mounting Nut
18	Coupling Nut
19	Lift Rod Knob
	Lift Rod
20	Pop-Up