

Care & Maintenance Guide

DAILY CARE

- Dust wooden frame with a soft, dry cloth.
- Vacuum cane or fabric surfaces using upholstery attachment.

SPILL MANAGEMENT

- Blot liquids immediately with a clean, absorbent cloth.
- Spot-clean fabric using mild soap and lukewarm water; blot, don't rub.
- Avoid ammonia, bleach, or solvent-based cleaners.

WOOD MAINTENANCE

- Every 6–12 months, treat exposed mango wood with a clear, food-safe furniture oil or protector.
- Tighten all Allen bolts after 3 months, then yearly.

ENVIRONMENT

- Indoor use only. Keep away from direct heat sources and prolonged sunlight to prevent warping or fading.
- Attach felt pads (included) to protect floors.