

Assembly Instructions

Caution : You must read this before you proceed

Care & Maintenance



- Not for commercial use. For residential use only.



- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Stains may be removed with mild soap solution and damp cloth.




- Children should not climb or jump on the furniture.







- Dust and pick-up spills using a clean, non-colored, lint-free cloth.

ACCENT CHAIR



PART LIST : N719P501317


LABEL	PICTURE	DESCRIPTION	QTY
A		BACKREST	1
B		CHAIR FRAME	1
C		SEAT CUSHION	1
D		LEGS	4

Hardware

LABEL	PICTURE	DESCRIPTION	QTY
①		BOLT (5/16 X 45MM)	4+1
②		BOLT (1/4 X 15MM)	16+1
③		FLAT WASHER (5/16)	4+1
④		LOCK WASHER(5/16)	4+1
⑤		FLAT WASHER (1/4)	16+1
⑥		LOCK WASHER(1/4)	16+1
⑦		ALLEN WRENCH	1


ASSEMBLY STEPS

Overview




THIS CHAIR HAS MULTIPLE PARTS AND MAY REQUIRE UP TO 30 MINUTES TO ASSEMBLE. TO GIVE YOU AN OVERVIEW OF THE CHAIR PARTS, THE ABOVE PICTURE IS TO HELP YOU PUT THE VARIOUS PARTS INTO PERSPECTIVE. PLEASE READ THROUGH THE INSTRUCTIONS BELOW TO FAMILIARISE YOURSELF WITH THE PARTS AND STEPS BEFORE ASSEMBLY.


STEP 1




A



B




C



D

Hardware



Unpack and place all the parts on a clean, non-marring surface.

STEP 2


① x 4



③ x 4





④ x 4



Place the Backrest (A) face down on a clean, flat surface. Position the Chair Frame (B) onto the Backrest (A) as shown in the illustration. Align the mounting holes on both parts carefully. Secure the assembly using Bolts (1), Flat Washers (3), and Spring Washers (4), then tighten with the Allen wrench (7).

STEP 3





Position the Chair Legs (D) onto the Chair Frame (B) in the correct mounting locations, as shown in the illustration.

Secure the legs using Bolts (2), Spring Washers (6), and Flat Washers (5), then tighten them with the Allen wrench (7).

NOTE: Ensure that both chair legs are facing outward, as shown in the illustration.

STEP 4




Position the Chair Legs (D) onto the Backrest (A) in the correct mounting locations, as shown in the illustration.

Secure the legs using Bolts (2), Spring Washers (6), and Flat Washers (5), then tighten them with the Allen wrench (7).

NOTE: Ensure that both chair legs are facing toward the rear, as shown in the illustration.

STEP 5




Place the chair on a flat surface. Check and ensure that all parts have been assembled correctly according to the instructions. Make sure the chair is level, then fully tighten all bolts (100%) in the order of assembly.

Finally, zip up the fabric cover on the underside of the Chair Frame (B).


NOTE: Ensure that all chair legs are installed in the correct orientation as shown in the assembly instructions.

STEP 6



Place the Seat Cushion (C) onto the Chair Frame, as shown in the illustration.

COMPLETED ASSEMBLY



Place the chair on a flat surface. Check and ensure that all parts are securely connected. This will help align all components correctly at the connection points. Ensure that all screws are fully tightened.

The chair is now **READY TO USE**.

NOTE: This chair is designed for use on a flat surface only.