#### **WARNING!!**

#### Furniture Tipping Risk.

Serious risk of severe or fatal crush injuries can occur from

furniture tipping over if not secured.

Children like to climb on furniture and Unsecured furniture can pose a serious danger.

Please follow all instructions and install the tip-over restraints provided.

In addition to installing the restraints, to help prevent tipover:

1. Unless specifically designed to accommodate, do not set


TV's or other heavy objects on top of this product.

- 2. Never allow children to climb or hang on top glass.
- 3. Do not step on the Table base

# **Assembly Instructions**

Caution: You must read this before you proceed


# **CONSOLE TABLE**



<u>Hardware</u>			
Label	Picture	Description	QTY
1		Screwdriver (not provided)	1
2		Hammer (not provided)	1
3		Power Drill (not provided)	1
4		Bracket	2
(5)		Wall Plug Screw (M6x16mm)	4
6		Wall Plug (10x38mm)	4
7		Restraint Strap	2
8	9	Knob	2

# Assembly Preparation

#### Before Beginning Assembly:





Read instructions, cover to cover-



Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-




• Assemble on a clean non-marring surface (packing foam)-



Save all packaging until finished-

## Assembly Steps

# Step 1



With help of your adult partner, carefully stand the Chest.

- 1.1 Put out the drawers and deassemble the Knob(®)with the help of Screwdriver (①) .
- 1.2 Install the Knob(®)on the drawers with the help of Screw driver (①) as pictured above.

Follow the same step 1 to attach the other knob(®).

CAUTION 1: When tightening these screws, tighten sequentially. If there is still wobbles, loosen the screws and execute this same process.

Ensure all screws are fully locked into position.

Caution 2: This can only be used on a flat, level surface.


#### **Console Restraint Device Installation Instructions**



Serious or fatal crushing injuries can occur from tipping furniture.


To help prevent tip-over: ALWAYS secure this furniture to the wall using Cabinet Restraint Device.

See product instructions for more ways to help prevent furniture tip-over.



### **Usage For Restraint Device:**

To secure Console Table against wall, attach two Brackets (4) on wall and product, use Restraint Strap (7) to connect the Brackets (4).



2.1) Drill two holes on wall at same height as Brackets (4) on Console Table with Power Drill (3).

You can mark these points in two ways as below:


1) Move the Console Table back to the wall. Mark two points same height as Console Table on the wall.

Note: The Brackets need to be secured to solid, load bearing surface. Please use a Stud Finder(not supplied) if needed to locate the Wall Frame.

- 2) Measure the height of the Brackets (4) with ruler/measuring tape and mark on wall to keep them accurate and same height.
- 2.2) Insert Wall Plugs (6) into drilled holes on wall with Hammer (2).

# Step 3

Attach Brackets (4) to Wall Plugs (6) using Wall Plug Screws (5) with Screwdriver (1).



Move Console to the wall.

Pull the Restraint Straps (⑦) through the Brackets (④) on the wall and Console Table one by one, and pull the Restraint Straps (⑦) tight.

This Console Table is now ready to use.

Caution: This Console Table can only be used on flat, level surface.

