




Barcelona Extension Dining Table



Item #.: 5402DT84RTXAW

Customer Service

customerservice@il-outdoor.com







Monday - Friday, 9:00a.m.– 5:00p.m. CST

Toll Free: 1-888-910-5646 Fax: (832)-201-9138

WARNING

Please read instructions carefully and thoroughly before assembling. Check parts against the parts list to make sure you have all the parts needed for proper assembly. Familiarize yourself with the inventory of parts and the accompanying illustrations to ensure safe and proper assembly. **DO NOT ATTEMPT TO ASSEMBLE IF PARTS ARE MISSING OR DAMAGED. IMPROPER ASSEMBLY MAY RESULT IN DAMAGE OR SERIOUS INJURY.**

Place the table on a non-abrasive flat surface to prevent scratching.

PART #.	DESCRIPTION	PICTURE	QTY
A	Table Top		1
B	Leg Collecting Bar		1
C	Table Leg		2
D	Umbrella Cover		1
E	Bolt with washers (M6 x 15)		24
F	Allen Wrench		1

1. Place the table top (A) upside down on a non-abrasive flat surface. Align the holes in table legs (C) with the holes in the table top (A), Loosely secure table legs (C) to the table top (A) with the bolt with washers (E). Do not tighten the bolts at this point.
2. Align the holes in legs (C) with the holes in the leg collecting bar (B), Loosely secure the leg collecting bar (B) to the legs (C) with the bolt with washers (E). Do not tighten the bolts at this point.
3. Check the alignment of all table legs (C), and adjust if necessary. Once the alignment is correct and all bolts are in place, Properly tighten all the bolts (E) using allen wrench (F). With the help of another person, carefully turn the table to the upright position.

Place umbrella cover (D) on table top (A). The table is ready for your enjoyment.

