
SIDEBOARD



CONTENTS

Safety and care advice	1
Components – panels	2
Components – fittings	3
Assembly instructions	4
Copyright	11
Door alignment	12

PLEASE READ THESE INSTRUCTIONS CAREFULLY AND KEEP FOR FUTURE REFERENCE

Warning: Please lift with care.

- •Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- ·Keep children and animals away from the work area, small parts could choke if swallowed.
- ·Make sure you have enough space to layout the parts before starting.
- •Do not stand or put weight on the product, this could cause damage.
- ·Assemble the item as close to its final position (in the same room) as possible.
- ·Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- ·We do not recommend the use of power drill/drivers *for inserting screws*, as this could damage the unit. Only use hand screwdrivers.
- •Safety note: If there is any chance of this unit being pulled over by children etc. it is recommended that the unit is secured to a wall using suitable fixings.
- Dispose of all packaging carefully and responsibly.


CARE AND MAINTENANCE

- ·Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- ·From time to time check that there are no loose screws on this unit.
- ·This product should not be discarded with household waste. Take to your local authority waste disposal center.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference

COMPONENTS — PANELS

Please check you have all the panels listed below:



PANEL LIST

PACK 1/1	į	7 Leg	x6
1 Top Panel	x1	8 Active Panel	x3
2 Left Side Panel	x1	9 Back Panel	x3
3 Right Side Panel	x1	10 Door - 1	x1
4 Vertical Panel - 1	x1	11 Door - 2	x1
5 Vertical Panel - 2	x1	12 Door - 3	x1
6 Bottom Panel	x1		



COMPONENTS — FITTINGS

Please check you have all the fittings listed below:

Α



Metal Dowel x 8

В



Lock (Ø15x9.5mm) x 8

C



Screw(Ø4x40mm) x 8

D



Wooden Dowel(Ø8x30mm) x 16

F



Handle x 3

G



Screw(Ø4x14mm) x 24

н



Metal Slide - Female Right x 12



Screw(Ø3x14mm) x 12



Back Support x 12

Κ



Big Bend Hinge x 4



Safety Device x 2



Middle Bend Hinge x 2

Ν



Screw(Ø3x12mm) x 6



Bumper x 2


TOOLS NEEDED


(We don't provide)




□□ Phillips Screwdriver x 1











Step 3























Congratulations! Now you have finished assembling the product. There may be some dust or hand marks on your item.

COPYRIGHT

All material in this instruction manual is copyrighted.

Any unauthorised use may violate worldwide copyright, trademark and other laws.

DOOR ALIGNMENT




Customer Attention:

To align doors and control gap in between doors. Product doors may need adjusting during and after assembly.

This can be done by adjusting appropriate screws. See below illustration.






Vertical Door Adjustment:

Loosen both screws on all hinges and lift the door to the desired height.

This allows an even space at the top and bottom between the door and frame.





Lateral Door Adjustment:

If door is hinge bound, (rubbing on frame as you close or open door) loosening screw shown and move the door in approriate direction. (In or out)





Horizontal Door Adjustment:

Rotate Screw clockwise or anticlockwise. This will produce an even gap between doors and frame.