

Lamp Shades

CSHASH010



9" x 12"

CSHACY010



7" x 10"

CPLAPL002



9" x 13"

CSHSCR010



8" x 12"

CSHMCRO10



14" x 20"

CCH5PL010



9" x 12"

CSHMPL010



14" x 20"

Electrical Cords

ELCORD009



Standard Blue Socket | E26 Max 60W
Cord Length: 5ft

ELCOPLO10/012/021/022/023



ELCOPLO23 Silver



ELCOPLO22 Orange



ELCOPLO10 White



ELCOPLO12 Green



ELCOPLO21 Pink

On/Off Switch | Polarized Plug • Standard Blue Socket | E26 Max 60W
Cable Length: 12ft

Fitting Instructions

1. Ensure the light is switched off and the bulb is cool. Remove the bulb from the fitting.

2. Unscrew the collar (fig. 1).

3. Position the lamp shade and then screw the collar back into position to secure the shade (fig. 2).

4. Replace the bulb.

Always ensure that the decorative elements do not touch the light bulb.

Use only with **60W** bulb or less.

Please keep these instructions for future reference.

