









Dining Chair



PART LIST

#A 	#B 	#C 	#D 
Back 2 PCS	Seat 2 PCS	Right Leg 2 PCS	Left Leg 2 PCS


HARDWARE LIST

#1 	#2 	#3 	#4 	#5 
M6 x 80mm	M6 x 60mm	M6 x 40mm		
Long Bolt 8 PCS (Extra 1)	Bolt 8 PCS (Extra 1)	Short Bolt 6 PCS (Extra 1)	Spring Washer 22 PCS (Extra 1)	Flat Washer 22 PCS (Extra 1)

#6 
M4
Allen Wrench 1 PC


Step 1 . Attach seat (part B) to back (part A) using long bolts (part #1), short bolts (part #3), spring washers (part #4), flat washers (part #5) and allen wrench (part #6).

NOTE: Please do not fully tighten bolts until unit is fully assembled.



Step 2 . Attach legs (parts C & D) to seat (part B) using bolts (part #2), spring washers (part #4), flat washers (part #5) and allen wrench (part #6).

NOTE: Please fully tighten all bolts at this time.



Step 3. Carefully turn unit upright. Repeat steps 1-2 to assemble remaining chair.

