



ASSEMBLY INSTRUCTION

HFSN-698

Ax1




Ex1



Fx1




Bx1




Gx5




Cx1



Hx4




Dx1



Ix1




①




②

FRONT



③



④

