










Single Record Storage Stand



PARTS LIST


A 	B 	C 	D 	E 
Left Panel 1 PC	Right Panel 1 PC	Bottom Panel 1 PC	Shelf 1 PC	Back Panel 1 PC
F 	G 			
Front Rail 1 PC	Leg 2 PCS			

HARDWARE LIST

#1  7*38mm	#2 	#3 	#4  1/4"*25mm	#5  1/4"*10mm
Tapping Bolt 5 PCS (Extra 1)	Cam Bolt 6 PCS (Extra 1)	Cam Lock 6 PCS (Extra 1)	Bolt 6 PCS (Extra 1)	Spring Washer 6 PCS (Extra 1)
#6  1/4"*13mm	#7  8*30mm	#8  M4	#9 	#10 
Flat Washer 6 PCS (Extra 1)	Wood Dowel 20 PCS (Extra 1)	Allen Wrench 1 PC	Cam Sticker 12 PCS (Extra 1)	Safety Strap Kit 1 SET

ADDITIONAL TOOLS (Not Provided)

Note: It is not recommended to use power tools during assembly.




Phillips Head Screwdriver

Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.

Step 1. Insert cam bolts (part #2) into pre-drilled holes of panels (parts A & B) using phillips head screwdriver.


Note: Do not over tighten cam bolts. Stop tightening once threads on cam bolt are no longer visible.



Step 2. Attach front rail (part F) to shelf (part D) using wood dowels (part #7).


Attach assembled unit (parts D & F) to right panel (part B) using cam lock (part #3), wood dowels (part #7) and phillips head screwdriver.

Note: Cam locks must rotate a full 180°. See pictured insert.




Step 3. Attach back panel (part E) to right panel (part B) using cam locks (part #3), wood dowels (part #7) and phillips head screwdriver.

Note: Cam locks must rotate a full 180°. See pictured insert.




Step 4. Attach left panel (part A) to assembled unit (parts D, E & F) using cam locks (part #3), wood dowels (part #7) and phillips head screwdriver.


Note: Cam locks must rotate a full 180°. See pictured insert.



Step 5. Attach bottom panel (part C) to assembled unit (parts A, B & E) using tapping bolts (part #1), wood dowels (part #7) and allen wrench (part #8).





Step 6. Attach legs (part G) to assembled unit (parts A & B) using bolts (part #4), spring washers (part #5), flat washers (part #6), wood dowels (part #7), allen wrench (part #8) and phillips head screwdriver.




Step 7. Carefully turn unit upright. Using cam stickers (part #9) cover cam locks (part #3) and bolts (part #4).


Important: Safety strap kit (part #10) must be installed to prevent tipping damage and/or injury.

NOTE: It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.



#9  x 12




#10	A	B	C	D	E
			 8*3*15mm	 8*4*35mm	
Safety Strap Kit 1 SET	Wall Anchor 1 PC	Bracket 2 PCS	Short Screw 1 PC	Long Screw 1 PC	Safety Wall Strap 1 PC

SAFETY WALL STRAP INSTALLATION

Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

1. Insert short screw (C) and safety wall strap (E) through bracket (B) and attach to back panel (part E) using phillips head screwdriver.
2. Drill a 11/32" hole where you want to secure the unit. The drilled hole will be at the same height as the hole in back panel (part E) where bracket (B) is attached. Tap wall anchor (A) into the hole.
3. Insert long screw (D) and safety wall strap (E) through bracket (B) into wall anchor (A) using phillips head screwdriver.

Note: This item is not intended for clothing storage use.



⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.



This is a permanent label.
Do not remove!