




This fixture will fit in 4" Pancake Box, 4/O J-Box and Non-metallic 4" J-Box

WARNING:

- Risk of electric shock. Disconnect power at fuse or circuit breaker before installing or servicing.
- To prevent early lamp failure, lamp should only be installed in operating environments between -20°C and +40°C (-4°F and 104°F)
- No user serviceable parts inside. To avoid electric shock do not disassemble product.
- This product is not intended for use in emergency light fixtures or exit signs.

ATTENTION:

Turn power off before inspection, installation, or removal.
Suitable for use in wet locations. Use only on 120VAC, 60Hz circuits.



Fixture	Diameter (D)	Height (H)
RSD4S	6.2" (157mm)	1.2" (31mm)