






Assembly Instructions

Extension Dining Table


PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer.




A (1 pc)
5mm


B (8 pcs)
M8 x 35mm



C (8 pcs)
Ø8mm


D (8 pcs)
Ø8mm

During assembly, hand tighten screws only. When the screws are in place, tighten completely.


Top Adjustment Instructions - In Case of Uneven Glass Top After Assembling Extension Dining Table

Step 1




Disassemble the screws to unlock the table base with a 5mm Allen key, and move the base on each side about 3 CM outwards.

Step 2



Loosen the 4 screws located on the underside of the top with a 5mm Allen key.


Step 3




Adjust the aluminum nuts as needed to align the center top section with the outer table leaves.

Top Adjustment Instructions - In Case of Uneven Glass Top After Assembling Extension Dining Table

Step 4



Step 5



Move the table base on each side back in place, and assemble with screws.