




ITEM NO. TVYL1855

Scan for manual,
video & advice.



If you have any questions or concerns,
don't hesitate to reach out to us.

Call us: +1(833)324-2464 (8 AM to 5 PM PST Monday-Friday)

Email: customerservice@hulalahome.com

MAINTENANCE AND WARNINGS

Thank You For Choosing Our Furniture.

Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.


NOTE :

This brochure contains IMPORTANT safety info. Please read and keep it for future reference.




Weight Limitation

200 LBS



Installation:
60 minutes.



Two Person



Before You Start

Please follow the steps below:



Unbox the package and check if all parts and accessories are complete.



If you find something missing, stop assembly and contact your supplier immediately.



Please do not completely tighten all the hardware until the entire assembly is completed! Be sure to tighten all the hardware once the assembly completed.



NOTE: Should be assembled on soft surface to keep balance.

After-Sales Service

- If you encounter any issues or need technical support during use, please contact our after-sales team. We offer long-term maintenance and warranty services.



Warranty



We strive to offer high , quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.



Are you having difficulty with assembly? Missing parts? Please send email with your order number to customerservice@hulalahome.com




For return, please check the return policy with the retailer or market place you bought from. Appreciate your purchasing from us. Pop up your life by our furniture piece!

Daily Maintenance

- Keep furniture away from heat.
- Do not use cleaning agents containing acids, alkalis, or corrosive substances, as they may damage the surface. It is recommended to use neutral cleaning agents or specialized furniture cleaners.
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, for residential use only.


Exploded Diagram

Please confirm that you have received all 2 boxes(box A/B),
then begin the assembly!




Parts List *(Canton A)*

A ×1




Top panel

B ×1




Bottom panel

K ×1




Back panel

L ×1



Left adjustable Shelf


M ×1



Right adjustable Shelf


Parts List (Canton B)

C ×1




Left side panel

D ×1




Right side panel

E ×1




Middle left panel

F ×1




Middle right panel

G ×2




The middle link bar

H ×2



Left door

I ×2




Right door

J ×2



Foots


N ×3



Drawer back panel


Parts List *(Canton B)*

O ×3




Drawer left side panel

P ×3




Drawer right side panel

Q ×3



Drawer bottom panel

R ×3




Drawer front panel

×1



Hardware Liste

1 ×3




Drawer hold hands

2 ×4



Door hold hands

3 ×10+1



Screw
Ø4*22mm

4 ×36+3



Screw
Ø3*15mm

5 ×24+2



Screw
Ø4*25mm

6 ×4




Screw
Ø4*39mm

7 ×4



Wall anchor

8 ×2




Tie

9 ×4



Anti-tip
component

10 ×4




Screw
Ø4*20mm

11 ×48+4



Screw
Ø3*15mm

12 ×8




Hinge

13 ×8



Shelf pin

14 ×2



Magnetic catch

15 ×1



Screwdriver

16 ×1




Allen key

Assembly Instructions

Step 1

1. Install leg (J) on of bottom panel (B).
2. Insert part (C/D) into part (B),make sure all holes aligned and then tighten it with allen key (16) as picture show.


16	 x 1	Allen key
----	---	-----------



Step 2

1. Install panel (G) into panel (E/F), make sure all holes aligned and then tighten it with allen key (16) as picture show.


16	 x 1	Allen key
----	---	-----------



Step 3

1. Install preassembled step 2 into the corresponding hole of bottom panel (B), make sure all holes aligned and use allen key (16) to tighten it as picture show.


16	 x 1	Allen key
----	---	-----------



Step 4

1. Use screw (4) to attach magnetic catch (14) to the corresponding hole of panel (A), tighten screw with screwdriver (15).




4	 x 4	Ø3*15mm
14	 x 2	Magnetic catch
15	 x 1	Screwdriver



Step 5

1. Install the top panel (A) into the corresponding holes in the pre-assembly step 4, make sure all the holes line up and tighten it with (16) allen key as shown in the picture.


16	 x 1	Allen key
----	---	-----------




Step 6

1. Install part (K) into the preassembled step 5, make sure all holes aligned and use screw (4) to attach them, tighten screw (4) with screwdriver (15).

4	 x 32	Ø3*15mm
15	 x 1	Screwdriver



Step 7




Attention:
Before the next step, adjust the feet of the locker to keep it level.


Step 8

1. Connect part (O&P) to part (R) using screw (5) and tighten it with screwdriver (15).
2. Slide in the part (Q) into the groove in part (O&P), make sure they are also they are also in groove in part (R).


5	 x 12	Ø4*25mm
15	 x 1	Screwdriver




Step 1



Step 2



Step 3




Step 9


1. Connect the (N) and (O&P) using screw (5), and tighten it with screwdriver (15).
2. Install handle (1) to panel (R) using bolt (3) and tighten it with screwdriver (15).

1		x 3	Drawer hold hands
3		x 6	Ø4*22mm
5		x 12	Ø4*25mm
15		x 1	Screwdriver



Step 1





Step 2



Step 10




**Schematic diagram of
slide rail disassembly**



Step 11

1. Use screw (11) to attach the hinges (12) to door panel (H)&(I), tighten screws with screwdriver (15)


11	 x 16	Ø3*15mm
12	 x 8	Hinge
15	 x 1	Screwdriver



Step 12

1. Use screw (11) to attach left door (H) and right door (I) to pre-assemble unit at step 11 ,tighten screw (11) with screwdriver (15) .


11	 x 32	Ø3*15mm
15	 x 1	Screwdriver




Step 13

1. Use bolt (3) to attach handle (2) to door panel (H)&(I), tighten bolts with screwdriver (15)


2		x 4	Door hold hands
3		x 4	Ø4*22mm
15		x 1	Screwdriver




Concealed hinges are three-way adjustable:




Horizontal
by screw adjustment!




Concealed hinges are three-way adjustable:




In-and-out
by loosening the hinge arm
mounting screw or via cam
adjustment!



Concealed hinges are three-way adjustable:



Vertical via slots in
the mounting plate
or via cam adjustment!



Hinge adjustment method




Scan for adj video

Step 14

1. Insert shelf pin (13) into Pre-assemble unit at step 13.
2. Attach adjustable shelf (L&M) to pin (13).


13	 x 8	Shelf pin
----	---	-----------



Step 15

1. Use screw (10) to attach plastic bracket (9) to panel (K), make sure all holes aligned and tighten screw (10) with screwdriver (15).



10	 x 4	Ø4*20mm
9	 x 2	Anti-tip component
15	 x 1	Screwdriver




Step 16

1.Install Anti-tip device (9) to the wall in this step.


9		x 2	Anti-tip component
6		x 4	Ø4*39mm
7		x 4	Wall anchor
15		x 1	Screwdriver



1.Drill a hole in the wall with an electric drill.



2.Tap the plastic wall anchor (7) into the hole with a hammer.



3.Secure the Anti-tip device (9) to the wall with screws (6)

Step 17

8	 x 2	Tie
---	---	-----



⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install anti-tip device provided.
- NEVER exceed the maximum size and weight of the TV shown in the instructions.
- NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

***This is a permanent label.
Do not remove!***



WWW.HULALAHOME.COM

Email: customerservice@hulalahome.com

Call us: +1(833)324-2464 (8 AM to 5 PM PST Monday-Friday)