


Dining Chairs Instruction Manual



Please read

1. Do not discard any packaging materials until you are certain that all parts and hardware are included.
2. Please dispose of all packaging materials in a safe and environmentally responsible manner.
3. During assembly, do not fully tighten any screws. Tighten all screws to approximately 50% first.
4. After all parts have been assembled and the chair is properly aligned, fully tighten all screws.
5. Place the chair on a flat surface and ensure it is stable before completing the final tightening.







Caution

- Never stand on the chair.
- Do not use the chair as a ladder.
- Check all screws every 6 months and retighten if necessary.
- Keep children away during assembly.
- Place the chair on a flat and stable surface before use.

Usage Troubleshoot

- If the upholstery is torn, stained, or damaged upon arrival, please contact us for a replacement part or appropriate assistance.
- If the chair frame or legs are bent, cracked, or damaged during shipping, please contact us for a replacement part or further support.
- If any hardware or parts are missing, please contact us and provide a photo of the package contents. We will arrange a replacement as soon as possible.
- If the chair feels unstable or wobbles after assembly, please ensure all screws are properly tightened and adjust the foot caps at the bottom of the legs to improve stability.
- If the chair remains unstable after adjustment, please contact us for assistance.

Accessories List


A-Front Leg Frame x1 	B-Rear Leg Frame x1 			
C-Backrest x1 	D-Cushion x1 			
E-Screws (M6×12mm) x4 	F-Screw (M6×30mm) x1 	G-Screws (M6×35mm) x4 	H-Screws (M6×45mm) x4 	I-Wrench x1 

Assembly Instruction

Step 1

Connect Frame A and Frame B using: Screw F ×1 Screw E ×4


⚠ A and B must not be reversed. Tighten screws to approximately 50%.



Step 2

Attach Backrest (C) to the frame using: Screw G ×4


Tighten screws to approximately 50%.



Step 3

Attach Seat Cushion (D) using: Screw H × 4

Tighten screws to approximately 50%.




Step 4

Ensure the chair is balanced before fully tightening all screws.
The adjustable foot caps can be used to level the chair.

After confirming stability:


- ✓ Tighten all screws to 100%
- ✓ Assembly completed



Safety Information



Do not sit on the
front edge



Do not stand on
the chair



One person only



Do not move the chair
while occupied



Do not lean back
excessively



Do not rock backward
on the chair

INSTRUCTION MANUAL