













Teileliste / Liste de pièces / Elenco delle parti / Parts list


	①*2		②*1		③*1
	④*1		⑤*1		⑥*1
	⑦*1		⑧*1		⑨*1
	⑩*1		⑪*1		⑫*1
	⑬*2		⑭*1		⑮*2
	⑯*3		⑰*1		

- A:  3.5*45 8
- B:  3.0*30 4
- C:  3.5*50 34
- D:  3.5*35 12
- E:  3




Ex3

1



!!Parts 11 and 12 must be aligned with the outer edge during assembly; otherwise, there will not be enough space to install the floor.!!



2




Ax4

3

Place the floor panel into position.




4




Bx4

5




Cx4

6




Cx3

7




Cx3

8




Cx7

9




Cx4

10




Cx3

11




Cx10


12




13




14




15




16



17



18



19