




User Manual




OMC25S103



Please read the instruction manual before assembly. Scan the QR code on the right to view the installation video and electronic manual.

Please keep the manual safe and transfer it with the product.





Scan for the e-manual





Scan for the installation video



1. Please keep this manual in a safe place and pass it on if you transfer the product to someone else.



2. Choose a clean, flat and spacious area for assembly, and avoid hard surfaces that could damage the product.



Scan the QR code to access.

1. Official after-sales support service
2. Product installation video
3. Warranty activation service

! If you encounter any problems during the installation process, please scan the QR code to contact us for assistance.

! Anti-tipping warning !

Furniture tip-over can cause serious or fatal injuries.

To prevent such incidents, please follow the recommendations below:



- Install the supplied tip-over restraint kit as instructed.
- Keep children from climbing on or leaning against the product.
- Do not place a TV or other heavy items on it unless it is designed to support them.
- If this product includes drawers:
 - Store heavier items in the bottom drawer.
 - Open only one drawer at a time to avoid instability.
 - Do not remove or tamper with drawers.

Note: The included anti-tip device reduces— but does not fully eliminate — the risk of tip-over. Please use this product with caution.


Warning

- This product is for indoor use only. Using the product outside of its intended purpose and/or modifying it beyond its original design may result in personal injury and/or product damage.
- This product must be assembled and used according to the instructions.
- The seller assumes no responsibility or liability for any damage caused by improper assembly or misuse.
- Children must not assemble this product. Keep small parts out of children's reach during assembly, as swallowing or inhaling them may be fatal.
- Children must not climb or stand on this product to avoid tipping and potential injury.
- Do not use this product if there are defects and/or missing parts, as this may cause damage or injury.
- If this product is equipped with an anti-tip device, be sure to install it to prevent the product from tipping over and causing unnecessary injury.
- If this product involves electrical components, keep it away from water or damp environments to avoid electric leakage or short circuits that may cause injury.
- If the product does not have wheels at the bottom, it cannot be moved. Do not drag it, as doing so may loosen or damage the product.


Maintenance Tips

- Place the product on a flat, stable surface to avoid uneven stress and potential damage.
- Periodically check the tightness of all screws during use. Retighten them if necessary to ensure structural integrity.
- Use heat-resistant pads for hot items. Keep the product away from air-conditioning vents or radiators by at least 1.5 meters. Do not place it in any high-temperature area to ensure longevity.
- Wipe off any water on the furniture surface promptly. Avoid exposing the product to long-term humidity to prevent mold.
- Do not place any corrosive substances (including alcohol, aromatherapy oils, nail polish remover, etc.) on the surface.


Accessory List-1




Accessory List-02




Prepare the
required tools.




screwdriver



hammer



electric
drill




tape
measure




Before installation, check that all boards and parts match the manual and distinguish similar parts by size. If anything is missing, scan the QR code to contact us.
Note: This product ships in two packages.

A*90




Cam wheel

B*90




Cam bolt

C*36




Wooden dowel

D*3




Door stopper

E*96




Short screw

G*12




Hinge

I*6




Handle

J*6




Flat-head screw

K*16




Back panel fastener

L*2




Anti-tip device

M*2




wall plug

N*6




Long screw

P*90







Cover cap

O*6




Drawer Slide




Drawer Slide Disassembly Steps



1.First, push the black lever upward.




2.Then, pull it out to the right (0.2)




1

As shown, tap the black Cam Nut(B.1) into panels 3 and 4.
Then use a screwdriver to screw the cam bolt (B.2) into the black Cam Nut.




B*8








Cam bolts

C*8




Wooden dowels


Insert the wooden dowels (C)
into panels 3 and 4.

Wooden dowel
DiagramCam bolt
DiagramUnscrew the
Cam NutHammer into
the holeScrew in the
Cam Dowel

2 Connect panel 3 to panels 1 and 2, and press the Cam wheel(A) into panels 1 and 2. Then rotate to tighten.




3




Then connect panel 4 to panels 1 and 2, and press the Cam wheel (A) into panels 1 and 2. Then rotate to tighten.

4

Rotate the cabinet body 90°




then slide back panel 5 into the grooves.




5


As shown, tap the black Cam Nut(B.1) into panel 6. Then use a screwdriver to screw the cam bolt (B.2) into the black Cam Nut.




Insert the wooden dowels (C) into panel 6.




Wooden dowel Diagram





Unscrew the Cam Nut




Hammer into the hole



Screw in the Cam Dowel



wooden dowel




Cam bolt




6

Then connect panel 6 to panels 3, 4, and 5, and press the cam lock (A) into panels 3 and 4.


Rotate panel 6 by 180° first.



Cam wheel
Diagram



Rotate in the
[+] direction




A*4

Cam wheel


7

As shown, tap the black Cam Nut(B.1) into panel 6. Then use a screwdriver to screw the cam bolt (B.2) into the black Cam Nut.




C*8

wooden dowel





B*8

Cam bolt



B.1 B.2





C


Insert the wooden dowels (C) into panel 6.



Wooden dowel
Diagram




Cam bolt
Diagram




Unscrew the
Cam Nut



Hammer into
the hole





Screw in the
Cam Dowel




8




As shown, connect panels 7, 14, and 15 to panel 6, and press the Cam wheel(A) into panels 7, 14, and 15.



A*6




Cam wheel


Cam wheel
DiagramRotate in the
[+] direction

9


As shown, tap the black Cam Nut(B.1) into panels 8 and 11. Then use a screwdriver to screw the cam bolt (B.2) into the black Cam Nut.







B.1 B.2



B*6




Cam bolts




Cam bolt
DiagramUnscrew the
Cam NutHammer into
the holeScrew in the
Cam Dowel

10

As shown, connect panel 8 to panel 9, and connect panel 10 to panel 11, then press the Cam wheel(A) into panels 9 and 10. Then rotate to tighten.



Cam wheel
Diagram





A*6




Cam wheel

11

First rotate the
assembly by 90°




A*4




Cam wheel


then connect panels 8 and 9 to panel 6, and panels 10 and 11 to panel 6. Press the Cam wheel(A) into panels 9 and 10. Then rotate to tighten.




12 As shown, use the short screws (E) to align and fasten the Drawer Slides (O.1) to the pre-drilled holes on panels 9 and 10.



13 As shown, slide back panels 13 and 15 into the grooves.





As shown, tap the black Cam Nut(B.1) into panel 16.
Use a screwdriver to screw the cam bolt (B.2) into the black Cam Nut (B.1).






B*6	C*8
Cam bolts	Wooden dowels

Insert the wooden dowel (C) into panel 16.





15


Rotate panel 16 by 180°.




As shown, connect panel 16 to panels 9, 10, and 14, and press the Cam wheel(A) into panels 9, 10, and 14. Then rotate to tighten.




16




As shown, tighten the long screws (N) into panel 16.






As shown, tap the black Cam Nut(B.1) into panel 16. Then use a screwdriver to screw the cam bolt (B.2) into the black Cam Nut.



17





Insert the wooden dowels (C) into panel 16.




18

As shown, connect panels 17 and 18 to panel 16, and press the Cam wheel(A) into panels 17 and 18. Then rotate to tighten.






A*4



Cam wheel




Cam wheel
Diagram







19

As shown, slide back panel 19 into the groove.




20 As shown, tap the black Cam Nut(B.1) into panel 20. Then use a screwdriver to screw the cam bolt (B.2) into the black Cam Nut.





Insert the wooden dowels (C) into panel 20.

21




As shown, connect panel 20 to panels 17 and 18, and press the Cam wheel(A) into panels 17 and 18. Then rotate to tighten.




22


As shown, tap the black Cam Nut(B.1) into panels 21, 22, 23, and 25. Then use a screwdriver to screw the cam bolt (B.2) into the black Cam Nut.



(Panels 21, 22, 23, and 25 each come in three pieces. Repeat this installation step 3 times.)




23




As shown, connect panel 24 to panel 21, and press the Cam wheel(A) into panel 24. Then rotate to tighten.

(Panel 24 comes in three pieces. Repeat this installation step 3 times.)




24 As shown, connect panels 22 and 23 to panels 21 and 24, and press the Cam wheel(A) into panel 24 and 21. Then rotate to tighten. (Repeat this installation step 3 times.)




25

As shown, connect panel 25 to panels 22, 23, and 24, and press the Cam wheel(A) into panels 22, 23, and 24. (Panel 25 comes in three pieces. Repeat this installation step 3 times.)




26






As shown, use the short screws (E) to align and fasten the Drawer Slides (O.2) to the pre-drilled holes on panels 22 and 23. (Repeat this installation step 3 times.)

27


As shown, adjust the drawer slides and install the drawers.






28 As shown in the illustration, fasten the door stoppers (D) using the short screws (E).






29 As shown, fasten the hinges (G) to panels 26, 27, 28, 29, 30, and 31 using the short screws (E).



E*24	G*12
	
Short screw	Hinge



30







As shown, fasten panels 26, 27, 28, 29, 30, and 31 to panels 3, 4, 7, 12, 17, and 18 using the short screws (E).





*For details, please refer to page 24: Hinge Adjustment Method.

31

As shown, install the handles (I) onto panels 26, 27, 28, 29, 30, and 31 using the flat-head screws (J).






32



As shown, install the back-panel fasteners (K) onto back panels 5, 13, 15, and 19 using the short screws (E).


33



As shown, attach the cover caps (P) onto the cabinet's Cam wheels (A).


As shown in the illustration, install the anti-tip device

1. Drill holes in the wall: The hole depth should match the length of the bolt.
2. Insert the wall plug: Insert the wall plug (M) into the drilled holes, ensuring they are fully embedded in the wall.
3. Fasten the long screw: Pass the long screw (N) through the Anti-tip device (L) and screw it into the wall plug (M). Do not overtighten.
4. Secure the furniture: Use the short screw (E) to fasten the bracket to the furniture panel. Do not overtighten.
5. Ensure stability: Make sure the mounting plates are firmly secured to both the wall and the furniture.




Hinge Adjustment Method

If any misalignment occurs after installation, adjust the screws to achieve the optimal position.



You can simply adjust the screws to change the overlay of the door panel relative to the side panel.

1. Loosen the fixing screw.
3. After adjustment, tighten the short screw to secure it.



2. Adjust the corresponding screw position as needed.

After-sales service

⚠ If you have any questions after receiving the product, please scan the QR code immediately to contact us so we can help you resolve the issue.


✉ Email: cs-omc@outlook.com

☎ WhatsApp: +86 18688756013



After-sales QR code

Return Guidelines




Return and Warranty Policy

1. If any parts are damaged or missing during installation, please contact us for replacement.
2. If you encounter any product problems during use, please contact us immediately.


Important Reminders:

1. Please be sure to keep the original product packaging for at least 30 days.
2. If you need to return the item, please disassemble all the accessories completely and send us photos for confirmation.
3. After taking photos, please pack all accessories completely and return them. You must contact us before returning the items.





Global Operator for Brand Expansion



OMCHOM

After-sales QR code

 Email: cs-omc@outlook.com

 WhatsApp: +86 18688756013