Assembly Instruction

Note:

1.Should be assembled on flat ground to keep balance.

2:Before completing the installation,do not tighten the screws.





It needs at least two people to install.

Before starting the assembly, you must read the whole manual and follow the instructions.

Assembly Instruction



Assembly Instruction

Hardware Parts

A M8*20 30 PCS	B M8*35 8 PCS	 C M8*40 5 PCS	D 4 # 1 PC			

Part list

①  1 PC	②  1 PC	③  1 PC	④  1 PC	⑤  2 PCS	⑥  2 PCS	⑦ 1 PC
⑧  2 PCS	⑨  2 PCS	⑩  1 PC	⑪  3 PCS	⑫  4 PCS	⑬  2 PCS	

Assembly Instruction

C	M8*40	4pcs
D		1pc



Assembly Instruction

A	M8*20	2pcs
D		1pc



Assembly Instruction

A	M8*20	8pcs
D		1pc

Note:When installing, keep this notch facing upwards.

Assembly Instruction

A	M8*20	8pcs
D		1pc

Note:When installing, keep this notch facing upwards.

Assembly Instruction

A	M8*20	4pcs
D		1pc



Assembly Instruction

A	M8*20	4pcs
D		1pc

Assembly Instruction

B	M8*35	2pcs	C	M8*40	1pc
D		1pc			



Assembly Instruction

A	M8*20	4pcs	B	M8*35	6pcs
D		1pc			



Assembly Instruction