






















ASSEMBLY INSTRUCTION


This installation manual is the correct version

Note: Distinguishing between the numbers 6 and 9 is different, with the number 9 underlined; Please tighten all screws by 60% first, and then tighten them by 100% after installation is complete.




1.x2 	2.x2 	3.x2 	4.x1 	5.x1 		
6.x1 	7.x1 	8.x10 	9.x2 	10.x2 		
11.x2 	12.x2 	13.x1 	14.x2 	15.x1 		
16.x1 	17.x2 	18.x1 	19.x1 	20.x1 	21.x1 	22.x1 
A.x8pcs  M8x50mm	B.x2pcs  M8x35mm	C.x4pcs  M6x60mm	D.x16pcs  M6x55mm	E.x28pcs  M6x35mm		
F.x4pcs  M8	G.x4pcs  M6	H.x10pcs  M8x18mm	I.x62pcs  M6x16mm	J.x1pcs  M6		
K.x1pcs  M8	L.x1pcs  5#	M.x8pcs  40x40mm	N.x2pcs  20x30mm	O.x20pcs 		
P.x2pcs 	Q.x2pcs  M4x10mm	R.x1pcs 	S.x1pcs 	T.x1pcs  4#	U.x12pcs  M6x30mm	


①




②




③




④






5




6




7




8




9




10




11




12




14






13



15




16




17

18




R

Q



18



19

