




TV Cabinet

User Manual



INTRODUCTION

Thank you for purchasing our products. Committed to providing customers with the best quality products and service has always been our lifelong goal. Before using the product, please read this instruction manual carefully to ensure correct use. Keep the instruction manual in a place where the user can find it at any




PRECAUTIONS

1. There are many components and accessories in the package. Each component and accessory is labeled with a letter or a number, check carefully before using any of them. Keep them away from children to prevent accidents.
2. Please install the product on a clean and soft underlay (such as carpet or cardboard) to avoid scratching or damaging the surface of the product.
3. The main components of the product are relatively heavy. Please pay attention to safety during installation.
4. The product is not stable during installation. Please do not move it randomly before it is completely installed.
5. If you have any questions during installation, please contact the customer service in time.

***PLEASE BE SURE TO FOLLOW THE INSTALLATION STEPS IN THE MANUAL TO AVOID UNNECESSARY LOSSES CAUSED BY IMPROPER INSTALLATION.**





















***IF YOU NEED FURTHER ASSISTANCE, PLEASE CONTACT THE CUSTOMER SERVICE**

PANEL LAYOUT



























Due to the large number of boards,in order to facilitate the installation, please place the boards in order after opening the parcel and then start the installation.

PARTS LIST



①  1pcs	②  1pcs	③  6pcs	
④  1pcs	⑥  1pcs	⑧  1pcs	
⑤  1pcs	⑦  1pcs	⑨  1pcs	
⑩  2pcs	⑫  2pcs		⑬  1pcs
⑪  2pcs			⑭  1pcs
⑮  1pcs	⑰  2pcs	⑱  2pcs	
⑯  1pcs		⑲  2pcs	⑳  2pcs

HARDWARE LIST

A  x4 = A  x4 = A1  x4 + A2  x4			
B  1pcs	C  4pcs	D  2pcs	E  1pcs
F  1pcs	I  2pcs	J  2pcs	M  48pcs
H  2pcs	K  4pcs	L  12MM 40pcs	N  32pcs
O  48pcs	P  8pcs	Q  4pcs	R  4pcs
S  16pcs	T  48pcs	 → U  2pcs  V 1pcs	
W  8pcs	X  15MM 13pcs		


TIPS

1. When installing the product, use a soft surface (such as carpet or cardboard) to avoid scratching or damaging the surface of the product.
2. Please try to use a manual screwdriver instead of electric screw driver. A manual screwdriver can be used to better control the tightness of the screws.
3. Do not use any glue.
4. The product is unstable before it is assembled. Please pay attention to the product installation sequence, and align all screws and screw holes before tightening.
5. The structure of this product can not meet the requirements of children climbing.



1


HOW TO SPLIT THE SLIDE RAIL



2

You will need

C	x4	D	x2	L	x28
---	----	---	----	---	-----




3

You will need

③

x6



4


You will need

M


x12

N




x12



A1	x2	S	x4	M	x4	N	x4
----	----	---	----	---	----	---	----




A1	x2	S	x4	M	x4	N	x4
----	----	---	----	---	----	---	----




7

You will need			
O	x4	T	x4



8

You will need			
O	x4	T	x4



9

You will need

O	x8	T	x8
---	----	---	----

10

You will need

O	x4	T	x4
---	----	---	----

11

You will need

12	x2		
----	----	--	--


12

You will need

I	x1	X	x2	M	x6	N	x6
---	----	---	----	---	----	---	----



As part I has an adjustable elliptical hole, you need to adjust the position of I before installing the screw X. After adjustment, part I will have enough suction to ensure that the cabinet door closes properly during use.




13

You will need


I	x1	X	x2	M	x6	N	x6
---	----	---	----	---	----	---	----




As part I has an adjustable elliptical hole, you need to adjust the position of I before installing the screw X. After adjustment, part I will have enough suction to ensure that the cabinet door closes properly during use.



You will need			
O	x12	T	x12




You will need									
E	x1	F	x1	G	x2	Q	x4	R	x4




16

You will need

J	x2	K	x2	L	x4	P	x4		
---	----	---	----	---	----	---	----	--	--





As part J has an adjustable elliptical hole, you need to adjust the position of J before installing the screw L. After adjustment, part J will have enough suction with magnetic part I, ensuring that the cabinet door closes properly during use.




17

You will need

H	x2		
---	----	--	--



18





You will need

L	x6		
---	----	--	--

19

You will need

K	x2	M	x8	P	x4		
---	----	---	----	---	----	--	--






20

You will need

A2	x2	S	x4
----	----	---	----

X2





21

You will need

M	x4		
---	----	--	--

X2




22

X2

You will need


O	x4	T	x4
---	----	---	----




23

You will need

O	x8	T	x8
---	----	---	----



24






25



26

You will need


U x2





27


You will need

L	x2	B	x1
---	----	---	----





28






You will need

V	x1	W	x8	X	x8		
---	----	---	----	---	----	--	--



Install backboard nails can effectively enhance the stability of the product and extend the life span of the product.





EN

INTRODUCTION

Thank you for choosing TV Stand. Please read the instructions carefully and keep them for future reference. If you need further assistance, please contact our customer service online via email.

PRECAUTIONS

1. When installing the product, use a soft underlay (such as carpet or cardboard) to avoid scratching or damaging the surface of the product.
2. Please try to use a manual screwdriver instead of electric screw driver. A manual screwdriver can be used to better control the tightness of the screws.
3. Do not use any glue.
4. The product is unstable before it is assembled. Please pay attention to the product installation sequence.
5. The structure of this product can not meet the requirements of the placement of heavy items and children climbing.

WARRANTY

We offer an **18-month** warranty after the original purchase date. If there are manufacturing defects on this product, please contact support by email with your order number and other details about the problem.

FR

INTRODUCTION

Merci d'avoir choisi Meuble TV. Veuillez lire attentivement ce manuel d'utilisation et conservez-le pour référence ultérieure. Si vous avez besoin d'une assistance supplémentaire, veuillez contacter notre service clientèle en ligne par courrier électronique.

PRÉCAUTIONS

1. Choisissez d'installer ces tables sur une surface douce, telle que tapis ou carton, pour éviter de rayer ou d'endommager la surface du produit.
2. Essayez d'utiliser un tournevis manuel au lieu d'un tournevis électrique. Un tournevis manuel peut être utilisé pour mieux contrôler le serrage des vis.
3. Ne pas utiliser de colle.
4. Le produit est instable avant l'assemblage complet. Veuillez faire attention à l'ordre d'installation.
5. Ces tables ne peuvent pas être utilisées pour placer des objets trop lourds. Ne laissez pas les enfants s'asseoir.

GARANTIE

Nous offrons une garantie de 18 mois depuis la date d'achat. S'il y a des défauts de ce produit, veuillez nous contacter par mail avec votre numéro de commande et d'autre détail de ce problème.

ES

INTRODUCCIÓN

Gracias por elegir Mesa de Mueble de TV. Lea atentamente las instrucciones y guárdelas para futuras referencias. Si necesita más ayuda, comuníquese con nuestro servicio al cliente en línea por correo electrónico.

PRECAUCIONES

1. Use una superficie suave (como una alfombra o cartón) al instalar el producto para evitar rayar o dañar la superficie del producto.
2. Intenta usar un destornillador manual, no eléctrico, el manual puede apretar mejor el tornillo de control.
3. No use ningún pegamento
4. El producto es inestable antes de ensamblarlo. Preste atención a la secuencia de instalación del producto.
5. La estructura de este producto no puede cumplir con la colocación de artículos pesados ni niños que suben.

DE

EINFÜHRUNG

Hallo! Vielen Dank, dass Sie sich für TV-Schrank. Lesen Sie bitte diese Bedienungsanleitung genau durch und bewahren Sie sie zum späteren Nachschlagen auf. Wenn Sie weitere Hilfe benötigen, wenden Sie sich bitte per E-Mail an den Kundenservice.

HINWEISE

1. Installieren Sie das Produkt bitte auf einer weichen Fläche (z. B. Teppich oder Pappe), um Kratzer oder Beschädigungen der Oberfläche des Produkts zu vermeiden.
2. Versuchen Sie bitte, einen manuellen Schraubenzieher statt eines elektrischen Schraubenziehers zu verwenden, weil manueller Schraubendreher den Straffheitsgrad der Schraube besser kontrollieren.
3. Verwenden Sie bitte keinen Leim
4. Das Produkt ist vor dem Zusammenbau instabil. Beachten Sie bitte die Installationsreihenfolge des Produkts.
5. Die Struktur dieses Produktes kann die Platzierung der schweren Gegenständen und das Klettern von Kinder nicht tragen.

GARANTIE

Wird bis **18 Monate** nach Originalkauf durch Produktgarantie abgedeckt. Wenn das Produkt irgendwelches Qualitätsproblem hat, kontaktieren Sie bitte unseren Kundenservice per Email, um Ihre Bestellnummer und Einzelheit des Problems zu senden. Wir werden die Probleme rechtzeitig für Sie lösen. Vielen Dank!

GARANTÍA

Ofrecemos una garantía de **18 meses** después de la fecha de compra original. Si hay defectos de fabricación en este producto, comuníquese con soporte por correo electrónico con su número de pedido y otros detalles sobre el problema.

IT

INTRODUZIONE

Grazie per aver scelto Mobile TV. Leggere attentamente le istruzioni e conservarle per riferimento futuro. Se hai bisogno di ulteriore aiuto, contatta il nostro servizio clienti online via e-mail.

PRECAUZIONI

1. Utilizzare una superficie morbida (come un tappeto o un cartone) durante l'installazione del prodotto per evitare di graffiare o danneggiare la superficie del prodotto.
2. Provare a utilizzare un cacciavite manuale, non elettrico, il manuale può stringere meglio la vite di controllo.
3. Non utilizzare colla
4. Il prodotto è instabile prima del montaggio. Prestare attenzione alla sequenza di installazione del prodotto.
5. La struttura di questo prodotto non può soddisfare il posizionamento di oggetti pesanti o arrampicarsi sui bambini.

GARANZIA

Offriamo una garanzia di **18 mesi** dopo la data di acquisto originale. In caso di difetti di fabbricazione su questo prodotto, contattare l'assistenza via e-mail con il numero dell'ordine e altri dettagli sul problema.