


# ARTISTICA®

— HOME —

## **ASSEMBLY INSTRUCTIONS**

2200-907 Appellation Media Console



### **Leveling Instructions:**

This case is provided with adjustable levelers/glides to allow proper door alignment when uneven floors are present. Levelers are already inserted in bottom of case. With case placed in desired location, slightly tilt case forward or backward as required to reach levelers. Rotate levelers clockwise to raise and counter-clockwise to lower.

**Adjustable wood shelves** are secured with screws through shelf supports on each end to stabilize them during shipping. To adjust shelves, remove screws from shelf supports (underneath shelf) with a small Phillips head screwdriver. Shelf can then be lifted out, supports moved to appropriate position, and shelf replaced. Use screwdriver to replace screws through shelf supports and into bottom of shelf.

For additional consumer assistance, please contact your local Artistica Home dealer or our Customer Services Department at 1-336-474-5300, Monday-Friday, 8-5 Eastern.