



## Stix LED Floor Lamp Assembly Instructions

1. Connect pole pieces together to assemble lamp legs, in descending order -(C) on top, (B) in the middle, and (A) on bottom. Repeat two more times.
2. Connect the assembled legs to the bottom of intersected section (D)- power cord should extend out of the bottom of section (D).
3. Connect light source poles (E) to intersected section (D).
4. Plug power adapter (F) into lamp connector first, then into outlet.

### Product Details:

- Light source poles can be rotated 360 degrees to change direction of light.
- The lamp is operated by a three way foot pedal dimmer, built into the power cord.
- The brightest light level has a maximum wattage of 18 watts.

Thank you for purchasing this Brightech product. We guarantee all of our products with a best-in-class warranty for any manufacturer defects. If you need assistance or are unsatisfied with your purchase. PLEASE REACH OUT TO US DIRECTLY.

at [wecare@brightech.com](mailto:wecare@brightech.com) or file a warranty claim at <https://www.brightech.com/pages/warranty-request>

**Brightech**  
www.brightech.com  
wecare@brightech.com

