



LEAF LED Floor Lamp

Assembly Instructions for the Brightech LEAF LED Floor Lamp:

1. Connect pole B to base A, then pole C to pole B and pole D to pole C. You may need to remove the protective covering from the threading on the base to start connecting the poles.
2. Connect head E to pole D, and you can adjust the reach and angle of the head at this point if desired.
3. Plug power supply into lamp first, then plug into outlet and power on.

Operation and Features:

The LEAF LED is controlled via a three step touch sensor button located at the top of the pole. Simply tap the button to turn on and cycle through the dimmer settings. It can be turned on and off via a wall switch for convenience, but it cannot be dimmed except by the touch sensor on the lamp. When using the lamp with a wall switch, it will remember its settings: if you turn the switch off with the lamp set to a lower brightness level, it will stay on the same lower level when you turn the switch back on.

Extend Your Warranty, Free :

If you would like to extend your warranty from 3 years to 5, free, fill in this short product registration form on our site :

<https://brightech.com/pages/extended-warranty>.

Thank you!

Thank you for purchasing from Brightech! If you have any trouble whatsoever with your order, please reach out to us via our site, www.brightech.com. We will be happy to assist you.

