
#### **ASSEMBLY INSTRUCTIONS**

#### FATIMA ROUND ACCENT TABLE






#### Please read below before assembly:

- Assemble the product on a flat, soft surface such as a carpet or cloth to prevent scratching the finish.
- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.
- Failure to follow these instructions may cause the bolts to misalign during assembly.


#### **DISCLAIMERS:**

- WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.
- BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE INSPECTED AT LEAST EVERY 3 MONTHS AND RE-TIGHTEN AS NEEDED TO PREVENT DAMAGE OR INJURY, AND ENSURE STABILITY.



# **PARTS LIST**

1	TABLE TOP		1 PC
2	MOUNTING PLATE		1 PC
3	POST	<b>◇</b> :  →	1 PC
4	LEG		4 PCS
5	BOTTOM FRAME		1 PC




# **HARDWARE LIST**


А	BOLT - Ø1/4"x1-1/2"		2 PCS
В	BOLT - Ø1/4"x1-1/4"		12 PCS
С	LOCK WASHER - Ø1/4"	<b>©</b>	14 PCS
D	FLAT WASHER - Ø1/4"	0	14 PCS
D	ALLEN KEY - 1/4"		1 PC

#### STEP 1

LOCATE PARTS AND HARDWARE PER BELOW DRAWING.




STEP 2




AFTER ALL LEGS ARE ALIGN WITH THE POST, TIGHTEN THE BOLTS.

## STEP 3

Α		1 PC
В		4 PCS
O	0	5 PCS
ם	0	5 PCS
Е	ſ	1 PC



### STEP 4



## STEP 3

Α		1 PC
В		4 PCS
C	0	5 PCS
D	0	5 PCS
Ε	ſ	1 PC

