







Assembly Instruction Massage Reclining Loveseet With Console

A*1 	B*1 	C*1 	D*1 	E*1 
F*1 	G*1 	H*1 	I*1 	



Massage Sofa Operation Instruction

READ ALL INSTRUCTIONS

BEFORE USING THE ITEM

MODEL:D-65-8JR-AB




Adopt America and European 2.4GHz solution,with strong anti-interfere feature

PRODUCT FEATURE

- 8 Vibration Motors Massage
- Heating
- Three Massaging modes
- Three Adjustable intensity
- Four massage zones, each zone can be operated individually
- The default timing is 15 min
- The product is 4 position motor massage core. Pull through it, it is in standby state. Users can realize the function control through the hand controller.

HOW TO USE

- 1、 Insert adapter jack into the socket found on back of the massage chair, then plug the adapter into a wall outlet. The specification of power adapter: input, AC110-240V, 50Hz; output, DC 12V, 2500mA.



- 2、  POWER: Press this button to turn on the massage function at the two positions AB at the same time, and operate the function button to adjust the two positions AB at the same time. To select individual A/B position massage function, operate the A/B button to adjust.

- 3、  Position A: The product is a two-seat sofa. A represents the massage position on the left side of the sofa. Press this button for full body massage in position A, and other function buttons on the remote control individually control position A. If you want to switch to the B massage position, please press the B button and the A position massage function stops. If you want to massage AB at the same time, please press the POWER button to switch.

- 4、  Position B: The product is a two-seat sofa. B represents the

massage position on the left side of the sofa. Press this button for full body massage at position B. The other function buttons of the remote control individually control position B. If you want to switch to the A massage position, please press the A button and the B position massage function stops. If you want to massage AB at the same time, please press the POWER button to switch.

- 5、 **MODE:** To choose a desired massage mode, press the MODE button. To change modes, press MODE button until desired mode Message. Product setting three mode gear options.
- 6、 **INT:** To change the massage intensity press the INT button. Product setting three intensity gear options.
- 7、 **Heating :** if users want the product to have the spontaneous heat, they can press heating switch key for heating. The maximum heating value is 65°C. There is a built-in protective chip in the product, and the continuous heating will not make the heat value exceed the maximum peak value.
- 8、 **Position:** Turn on the power and massage four position at the same time. You can operate this button according to your needs. The parts are waist-thigh-leg-back---.
- 9、**Time:** the default preset time of the product is 15 minutes. After it is used for 15 minutes, the product will shut down automatically for protection.
- 10、**NOTE:** Discontinue use immediately if you feel any discomfort or pain.
- 11、**NOTE:** for your benefit, the massage chair is equipped with an

auto shut-off feature that will turn the chair unit off after 15 /30minutes of continuous use.

12、 DO NOT use for more than 30minutes of continuous use.

MAINTENANCE INSTRUCTIONS

TO STORE:

Place unit in its box or safe, dry, cool place. Avoid contact with sharp edges or pointed objects which might cut or puncture the fabric. Do not wrap power cord around the unit. Do not hang the unit by power cord.

TO CLEAN:

- Insure the unit is unplugged from the power source, and allow to cool before cleaning.
- To clean the unit, make sure the massager is unplugged. Allow the unit to cool and the wipe down with a damp clean cloth. Do not use any strong chemical cleaners.

END