
8.2x8.2 ft Solar Powered LED Lights Patio Offset Umbrella



Tips: Weight base is not included in this item. Please buy it separately. The recommended minimum total weight of the base is 150 LBS.

Need help or have any questions? Our Professional Service Team is ready to assist you. Don't hesitate to reach out to us at service@usavingmall.com or call us at **949-866-8000** for any support or further assistance. We are committed to providing excellent service.

User Manual

General Guidelines :

- Please read the following instructions carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps.
- Please contact us when further information and help are needed.

Notes :

- Personal injury and/or damage to the product may occur if products are used outside of their intended purposes and/or if products have been changed/modified from their original design. The product must be assembled and used in accordance with the provisions of the manual. The seller does not assume any responsibility or liability with respect to any damage caused by incorrect assembly or improper use.
- Carefully check accessories when opening the package. If anything is missing or damaged, please contact us immediately.
- Do not use the umbrella without an umbrella stand (NOT included).
- This umbrella is only used for shading and decoration purposes.
- Store the umbrella in a dry, sheltered place, such as a garage or basement during high winds, rainy days, and the off-season.
- Never force your umbrella open. The umbrella mechanics should open gently and easily.
- Do not use sharp tools or equipment such as a knife or scissors when removing the protective material, as it may damage the product.
- After receiving the product, connect the LED light plug to the solar panel before using it.
- Put the solar umbrella in direct sunlight to charge the batteries for 8 hours before the first use.



Warnings :

- Keep children away when assembling the product. Small parts are included in the package; they may be fatal if swallowed or inhaled.
- To avoid the potential dangers of suffocation, please keep all parts and packaging (film, plastic bags, foam, etc.) away from babies and children.
- Keep the umbrella away from fire; do not use it during extreme cold and heat, and severe weather conditions like rainy, windy, snowy days, and hailstorms, etc.
- When the battery needs to be replaced, please use a battery of the same specifications and capacity.
- Do not throw the battery into fire or heat.
- The battery should be recycled or treated according to state or local requirements.

Daily Maintenance :

- Clean the canopy with a soft cloth moistened with a neutral detergent.
- Store it after completely drying, which will help reduce the growth of mold.
- Do not machine wash, do not dry.
- Do not iron.


Package Contents



Part	Description	Quantity
B	Hex Bolt (M8x20)	4
C	Flat Washer (M8)	4
D	Lower Cross Leg	1
E	Upper Cross Leg	1
F	Holder Pole	1
N	Umbrella frame with Canopy	1
S	Solar Panel	1
G	Wrench	1


1

- Insert the plug into the socket under the solar panel. Put the solar panel on the top of umbrella and hide the plug and wire inside the groove at the top of umbrella. Then turn the solar panel clockwise.
- Do not over tighten. Please remove the plastic film on the solar panel. This protective plastic film is to prevent damage during shipment.
- Put solar umbrella under the sunlight for 8 hours to charge battery for first use. Charging for less time will shorten lifespan of battery and decrease performance.
- Ensure the switch on the umbrella rib is in OFF position. Solar panel will not be charged if lights are switched to ON position.




2

Place the upper cross leg (E) on the top of lower cross leg (D). Then attach the holder pole (F) to the cross legs, insert the bolts (B) and washers by wrench (G). Adjust the holder pole (F) to be sure that it is positioned correctly on the base and tighten the bolts. Be careful to not over tighten the bolts.




3

Loosen the two control knobs, then Insert the pole of the Umbrella Frame with Canopy (N) into the Holder Pole (F). Tighten the two control knobs to secure the main pole.



4


Unlock the trigger and push up the arm and open the umbrella.



Tips: Weight base is not included in this item. Please buy it separately. The recommended minimum total weight of the base is 150 LBS.


5

Push up and fully open the umbrella arm. Lock the trigger.



6

Open the folded crank as below drawings. Then open the canopy by the handle. Turn on the light by pressing switch to ON position.



7

After finish using, please make sure the switch on the umbrella rib is in OFF position. Then close the canopy by turn the handle counterclockwise, unlock the trigger, pull down the umbrella arm, lock the trigger and fasten the storage straps.

