



ASSEMBLY INSTRUCTION

Item Number: N606P448280 N606P448281 N606P448282-4ft6-DOUBLE
N606P448283 N606P448284 N606P448285-5ft-KING








TIPS

1. This product is divided into 3 parcels for delivery. They may not arrive at the same time. Please wait patiently.
2. Please read the instructions fully before assembly. These instructions include important information which could ensure correct assembly. We have been working on providing high quality products for you. However, in the rare instance that your product is defective, missing parts or there are some issues, please don't hesitate to contact our customer service to submit parts requirements, assembly suggestion, or warranty claims, and we will give the best solution as soon as possible. If necessary, we need you to provide some more clear pictures of the issue.
3. Insert the screws in holes and tighten the screws, but not too tight, 70%~80% is ok, finally tighten all the screws. If some issues happened that some screws can not target to the hole or some parts are difficult to install, please adjust the tightness of the screws.
4. 2 people are recommended to finish














Part List

N606P448280 / N606P448283










1L1pc 	1R 1pc 	6 2pcs 
7 1pc 	17 2pcs 	21 1pc Cover 

N606P448281 / N606P448284

3L1pc 	3R 1pc 	4L 1pc 
4R1pc 	8L 1pc 	8R 1pc 
14 2pcs 	15 1pc 	16 2pcs 
20 2pcs Cover 	21 1pc 	

















Part List

N606P448282 / N606P448285


2 1pc 	5 1pc 	9 2pcs 
10 1pc 	11 1pc 	12 3pcs 
13 DOUBLE x 12PCS KING x 13PCS 	18 1pc 	19 1pc 
22 1pc 		

Hardware List

N606P448281 / N606P448284


A1pc 	B2pcs  M4x40mm	C3pcs  M6x45mm
D4pcs  M8x25mm	E22pcs  M8x20mm	F8pcs  M8x30mm
G37pcs  M8x40mm	H2pcs  M8x50mm	J36pcs 
K19pcs 	L1pc 	M1pc 
N1pc 	P2pcs 	Q2pcs 
R2pcs 	S8pcs 	T DOUBLE x 24PCS KING x 26PCS 

Step 1




Step 2

A x 1	E x 4	G x 16	J x 16	M x 1
	M8X20mm	M8X40mm		




A x 1	E x 4
	M8X20mm

Step 3



A x 1	G x 8	J x 8
	M8X40mm	


Step 4



NOTICE:
The hole on the gas lift is oval, Please ensure that the installation positions on the left and right are roughly the same, If you accidentally install the gas lift one side to the front and the other to the back, which affects your use, you can knock it down and reinstall it.


A x 1	F x 8 M8X30mm	S x 8
-------	------------------	-------

Step 5




<https://youtu.be/rHlgWA4aS3s>
Wenn sie bei der installation des ganzen busses probleme haben,
können sie den zweistufigen code einscannen,
um die installation des videos zu sehen

Step 6




A x 1	B x 2 M4X40mm	E x 6 M8X20mm	N x 1	R x 2
-------	------------------	------------------	-------	-------


Step 7



Step 8



Step 9




https://youtu.be/fMEBxLT_tbw

Wenn sie bei der installation des ganzen busses probleme haben, können sie den zweistufigen code einscannen, um die installation des videos zu sehen


Please wait for 48 hours to allow the bed frame to fully expand.

If there are uneven areas, gently pat the bed frame cover to smooth out any wrinkles that may appear on the surface.


Step 10




Step 11




Step 12




Step 12




Step 13





Step 14



Step 15



Step 15



WHY WON'T MY HYDRAULIC BED STAY DOWN?

1. In fact, nine times out ten the reason why hydraulic won't close is because you need to put your mattress on top of the bed. Yep, it really is that easy. This is because the hydraulic pistons need the weight of the mattress to provide enough pressure to close your bed.
2. However, what if you've put your mattress on your bed and you're one of the unlucky ones who finds that their hydraulic bed still won't stay down?

As previously mentioned, they require pressure in order to close. However, occasionally as well as placing the mattress on the bed you will initially have to apply some physical force yourself to close the bed. Don't worry you won't break it! ! !