

# INSTALLATION
*Product Manual*

Version: 590076US-01-26A-PF




### *IMPORTANT INFORMATION!*

please read the entire manual before starting to assemble and/or using this product.follow the manual thoroughly and keep it for further reference.




### *AVOID SCRATCHES!*

In order to avoid scratching this furnuture should be assembled on a soft layer-could be a rug.



### *IMPROVE EFFICIENCY !*

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



### *ANTI-TOPPLE WARNING !*


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

### *IMPORTANT !*

It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly,and once every 3 months - in order to assure stability through-out the lifespan of the product.







For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag.For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.


Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.









When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size


| A x 33 | B x 33 | C x 6 | D x 29 | E x 86 |
|---|---|---|---|---|
|  M5 x 42 mm |  M15 x 10 mm |  M8 x 40 mm |  M5 x 40 mm |  M3.5 x 12 mm |
| **F x 2** | **G x 12** | **H x 12** | **I x 4** | **J x 4** |
|  M3.5 x 14 mm |  M4 x 8 mm |  M4 x 20 mm |  1731 |  8807-192 |
| **K x 65** | **L x 9** | **M x 8** | **N x 1** | **O x 4** |
|  M6 x 10 mm |  M6 x 30 mm |  M6 x 50 mm |  M6 |  35-12D-LB |
| **P x 4** | **Q x 10** | **x 1** | **x 1** | |
|  35-12D-MW | Q-1  Q-2  M3.5 x 14 mm |  #4 |  10mm 12mm | |









## ⚠WARNING







**Children have died from furniture tipover.To reduce the risk of furniture tipover:**

- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand,climb or hang on drawers,doors,or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

*This is a permanent label.*
*Do not remove!*




ASSEMBLED BY 2 ADULTS


**Sllides Must Be Separated Before Assembly.**
**After Separated, Set Aside Until Needed for Assembly.**

Las diapositivas deben separarse antes del montaje.
Después de la separación, déjelo a un lado hasta que sea necesario.

Les glissières doivent être séparées avant I'assemblage.
Après la séparation, mettez de côté jusqu'au moment de I'assemblage.





**STEP 1: Extend Sllde**
Extender la diapositiva
Extendre la diapositive




**STEP 2: Push Lever UP**
Empujar hacia arriba
Lever le levier

**STEP 3: Remove Runner**
Quitar el corredor
Enlever le coureur




1

| K x 10 | x1 | |
|---|---|---|
| M6 x 10 mm | #4 | |

Secure boards 16 and 17 to iron frame 1 using bolt K.

**Pay attention to the installation direction of board 17.**




# 2

| K x 10 | x1 | |
|---|---|---|
|  |  | |
| M6 x 10 mm | #4 | |

Secure boards 16 and 18 to iron frame 2 using bolt K.


**Pay attention to the installation direction of board 18.**



# 3

| L x 6 | x1 | |
|---|---|---|
|  |  | |
| M6 x 30 mm | #4 | |


Secure iron frames 1, 2, and 4 using bolt L.



# 4

| K x 8 | x1 | |
|---|---|---|
|  |  | |
| M6 x 10 mm | #4 | |


Secure iron pipe 6 to iron frames 1 and 2 using bolt K.



# 5

| L x 3 | x1 | |
|---|---|---|
|  |  | |
| M6 x 30 mm | #4 | |


Secure iron frame 3 to iron frame 4 using bolt L.



# 6

| K x 32 | x1 | |
|---|---|---|
|  |  | |
| M6 x 10 mm | #4 | |

Secure iron pipe 5 to iron frames 1, 2, and 3 using bolt K.




7


G x 12



M4 x 8 mm



Secure slide rail 31 (part 1) to iron frame 3 using bolt G.




# 8


E x 14




M3.5 x 12 mm




Secure slide rail 31 (part 1) to boards 17 and 18 using screw E.



# 9


| K x 5 | N x 1 | x1 | x1 | |
|---|---|---|---|---|
|  |  |  |   | |
| M6 x 10 mm | M6 | #4 | | |

Secure iron part 7 to iron frames 1 and 2 using bolt K, then secure iron part 7 using bolt K and nut N.





10

A x 9




M5 x 42 mm







Screw eccentric rod A onto board 8.




# 11

| B x 9 | C x 6 | |
|---|---|---|
|  |  |  |
| M15 x 10 mm | M8 x 40 mm | |




Connect board 8 to boards 10, 11, and 12 using dowel C, then tighten by turning eccentric cam clockwise.



# 12

Insert board 13 along the slots of boards 8, 10, and 12.




13


D x 9



M5 x 40 mm



Secure board 9 to boards 10, 11, and 12 using screw D.




14


F x 2



M3.5 x 14 mm



Secure board 13 to board 11 using screw F.




15


Q x 10

Q-1 Q-2

M3.5 x 14 mm

Insert clip Q into back slots and secure them using provided screws.





16

Pay attention to the difference between the middle parts of the two types of door hinges.

- The full coverage door hinges (O) are used on the outermost left and right door plates.
- The curved door hinges (P) are used on the middle door plates.





O




P


# 17

| E x 8 | H x 2 | I x 2 | O x 4 | |
|---|---|---|---|---|
|  |  |  |  |  |
| M3.5 x 12 mm | M4 x 20 mm | 1731 | 35-12D-LB | |




Secure hinge O to boards 14 and 15 using screw E, then secure knob I using bolt H.







# 18


E x 16




M3.5 x 12 mm





Secure boards 14 and 15 to boards 10 and 12 via the hinges using screw E.







# 19

| E x 8 | H x 2 | I x 2 | P x 2 | |
|---|---|---|---|---|
|  |  |  |  |  |
| M3.5 x 12 mm | M4 x 20 mm | 1731 | 35-12D-MW | |




Secure hinge P to boards 14 and 15 using screw E, then secure knob I using bolt H.





20

E x 8




M3.5 x 12 mm






Secure board 15 to board 11 via the hinges using screw E.




21


E x 8




M3.5 x 12 mm




Secure board 14 to board 11 via the hinges using screw E.




# 22



If the door panels are not aligned, please adjust the screws on the hinges according to the illustration.




Or you can search this link to view the teaching video.
https://youtu.be/n0Lb36SoODM



# 23

| M x 8 | x1 | |
|---|---|---|
|  |  | |
| M6 x 50 mm | #4 | |

Secure iron pipe 6 and board 9 using bolt M.




# 24


D x 20



M5 x 40 mm





Secure boards 23, 24, 25, and 27 using screw D, and secure boards 27, 28, 29, and 30 using screw D.






# 25


Insert board 26 along the slots of boards 23, 24, and 25, and insert board 26 alonng the slots of boards 28, 29, and 30.








# 26

| A x 12 | H x 4 | J x 2 | |
|---|---|---|---|
|  |  |  |  |
| M5 x 42 mm | M4 x 20 mm | 8807-192 | |



Screw eccentric rod A onto boards 19 and 20, secure handle J using bolt H.








# 27

B x 12




M15 x 10 mm









Connect boards 19 and 20 to boards 23, 24, and 27, then tighten by turning eccentric cam B clockwise.




# 28

| A x 12 | H x 4 | J x 2 | |
|---|---|---|---|
|  |  |  |  |
| M5 x 42 mm | M4 x 20 mm | 8807-192 | |



Screw eccentric rod A onto boards 21 and 22, secure handle J using bolt H.




29


B x 12



M15 x 10 mm



Connect boards 21 and 22 to boards 27, 28, and 29, then tighten by turning eccentric cam B clockwise.




30

E x 12



M3.5 x 12 mm

Secure slide rail 31 (part 2) to boards 23 and 24 using screw E.




# 31


E x 12



M3.5 x 12 mm


Secure slide rail 31 (part 2) to boards 28 and 29 using screw E.



# 32

Insert the assembled drawers into the unit via slide rail 31.



# WARRANTY

## WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.

- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.

- The product must be used in accordance with the instructions provided. For health reasons.

- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

## Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.

- Does not include damage during installation, but includes damage during transportation.

## Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.

- After using, the damage and scratches of the furniture are not covered by the warranty.

## The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.

- Electrical parts: 1 month from the date of purchase.

# RETURNS

## CHANGED YOUR MIND AND NEED TO RETURN YOU ITEM?

## PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

## DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

## DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
  In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.

## AFTER-SALES CONTACT



adelahu@fufugaga.com


208-820-0068