

### **NOTICE**

- \* Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- \* This item may require periodic tightening.
- \* If you are having difficulty, our friendly Customer Care team is always here to help.

### **PREPARATION**




- \* Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- \* If any part is missing or damaged, do not attempt to assemble the product.
- \* Estimated Assembly Time: 10 minutes.

### **CARE AND MAINTENANCE**

- \* Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.
- \* The use of steam or water-based cleaners may cause excessive shrinking or staining.

**Dimensions:49.2"W\*22.6"D\*17.7"H**

### **Part List and Hardware List**




| PIECE | DESCRIPTION    | PICTURE  | QUANTITY |
|-------|----------------|--|----------|
| A     | Seat           |  | 1X       |
| B     | Legs           |   | 4X       |
| HW1   | Plastic Washer |  | 5X       |
|       |                |  |          |
|       |                |  |          |
|       |                |  |          |



- Weight Capacity: 550 lbs**
- Warning: Do not stand on Bench**
- Warning: Do not over torque bolts**

**PREPARATION**

- \* Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- \* If any part is missing or damaged, do not attempt to assemble the product.
- \* Estimated Assembly Time: 10 minutes.
- \* If you are having difficulty, our friendly Customer Care team is always here to help.

|   |  |
|---|--|
|   |                                 |
| <p>STEP1 OPEN THE ZIPPER ON THE UNDERSIDE OF THE SEAT AND TAKE OUT LEGS AND HARDWARE</p>  | <p>STEP2 ROTATE THE LEGS UNTIL TIGHTEN AS SHOWN IN THE PICTURE. CLOSE THE ZIPPER ON THE UNDERSIDE OF THE SEAT.</p> |
|   |  |
| <p>STEP3 PUT THE BENCH UPRIGHT AND MAKE SURE ALL LEGS ARE LEVEN. IF THE BENCH WOBBLY, YOU CAN ADJUST LEGS BY ADDING PLASTIC WASHER(HW1)BEFORE ROTATING.</p> |  |