


ASSEMBLY INSTRUCTION
ACCENT CHAIR

LEGS AND HARDWARE ARE STORED IN THE BOTTOM OF THE SEAT, PLEASE TAKE OUT FOR ASSEMBLY.


NO.	PARTS LIST	QTY	DESCRIPTION
A		1	ACCENT CHAIR

NO.	HARDWARE LIST	QTY	DESCRIPTION
B	 80mm*80mm*120mmH	2	WOODEN LEGS
C	 77mm*50mm*120mmH	2	WOODEN LEGS
D	 M8*75mm	4	BOLT
E	 M5*100*38mm	1	ALLEN KEY


ASSEMBLY INSTRUCTION
ACCENT CHAIR

STEP # 1

PARTS INSIDE



STEP # 2



CARE INSTRUCTION FOR POLISHED MICROFIBER FURNITURE

In order to maintain the original appearance of your polished microfiber furniture, please follow below simple care procedures.

°Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Exposure to sunlight or heating and air conditioning outlets will fade/damage polished microfiber .

°Wipe gently with a damp soft cloth to remove dust , dirt and any grime build up.