

ASSEMBLY AND INSTALLATION INSTRUCTIONS

1. Easy Installation Steps

Step 1: Cover the solar panel to check if the light operates properly.

Step 2: Press the power switch to turn on the light and select your preferred lighting mode.

Step 3: Mark the hole positions on the wall and drill the holes.

Step 4: Insert the wall anchors, screw the bracket firmly into place, and snap the solar light securely into the bracket.

Step 5: Ensure the solar light is installed in a location that receives 6 to 8 hours of direct sunlight daily.

Step 6: The light will automatically turn on at night.

2. Installation Precautions Do not install the product in shaded areas, such as under eaves or trees where sunlight is blocked. Avoid placing the light near other nighttime light sources (e.g., streetlights), as this may prevent the sensor from working.

3. Precautions for Use

IMPORTANT: Ensure the switch is turned ON before use.

If it is turned OFF, the light will neither turn on nor charge.

Keep the solar panel and motion sensor clean by regularly wiping away any dirt or debris to maintain optimal charging efficiency.


During cloudy days or winter, charging efficiency decreases, which may result in longer charging times and shorter operating hours.

This is normal for solar-powered products and is not a malfunction. The solar light automatically turns on at dusk and turns off at dawn.

WARNING: Do not dispose of the product or its batteries in a fire, as extreme heat may cause an explosion.

CAUTION: Do not attempt to disassemble the product by yourself.

Note: Cover the solar panel before pressing the switch; otherwise, the light may not operate correctly.



Mode Switching and Power ON/OFF Instructions

Mode 1 (Dim Light + Motion Sensor Mode):

When motion is detected, the light turns on at 100% brightness. After no motion is detected for 25 seconds, the brightness automatically reduces to 3%.

Mode 2 (Constant Low-Brightness Mode):

The light remains on all night at 20% brightness.

Mode 3 (Motion Sensor Mode):

When motion is detected, the light turns on at 100% brightness. After no motion is detected for 25 seconds, the light turns off automatically.