




N × 2




1# × 6




1#



1#



STEP 2




P × 2


R × 4

1# × 8


Q × 2




STEP 2




P1 × 2




Q1 × 2





Q2 × 2



1# × 4




11# × 8




11#

1#



11#




STEP 2




Don't forget to stick the velcro between the bug netting




STEP 2




T1 × 2





R × 4




1# × 8




T2 × 2




STEP 2



STEP 3




V1 x 2



V3 x 2



V4 x 2



Z1 x 4




V2 x 2



V6 x 2




V5 x 2




Z x 8



Z2 x 4




Z1



V1

Z2




V2

Z


Z

Z1

Z




V3




V4

Z2



V5



Z



V6

STEP 3

If you can't install **V4** or **V5**, push the part K up and try to insert them again.



STEP 3

V1

V2

V3



V4

V5


V6

1#

Fully fasten the 1# bolts in K & K1.



STEP 3




U1 × 4

U3 × 4


U4 × 4

U2 × 4

1# × 24



STEP 3



W1 x 2 

W2 x 2 

W3 x 2 

Z x 24 






W6 x 2 

W5 x 2 


W4 x 2 

Z3 x 2 

Z4 x 2 



STEP 3



X1 x2 

X2 x2 

X3 x2 

X4 x2 

Z x24 

Z3 x2 



X8 x2 

X7 x2 

X6 x2 


X5 x2 

Z4 x2 




STEP 3


Install the middle panels (X4 , X5 or W3 , W4) then the small panels on the edge.




STEP 3





5#×64



10#×4




S×68



10#×4


S




5#×64


S

STEP 3








6#×8




7#×28




S×36




6#×8



7#×28



STEP 3




STEP 4




B2 × 2



1# × 16



C2 × 2




STEP 4




D2 × 2



1# × 20




E2 × 2






STEP 4



Y × 4




Y1 × 4





STEP 4

There are 12 hooks in width(6 in each side).






Y1




STEP 4


There are 14 hooks in length(7 in each side).





STEP 4




STEP 4



STEP 4



STEP 4



STEP 4

Care and Cleaning

Wash frame parts and fabric with mild soap and water, rinse thoroughly.

Dry frame completely and allow the fabric to drip dry.

Do not use bleach, acid, or other solvents on the fabric or frame parts.

Please inspect and tighten all bolts or fasteners on a regular basis to ensure proper performance and safety of your gazebo.

Warranty

Frames

Frames constructions are warranted to be free from defects in material and workmanship for 1 year from item purchased. Damage to frame from negligence won't be covered by this warranty.

Netting

Netting are warranted to be free from defects in material and workmanship for 1 year from item purchased. Damage from exposure to chemicals (including but not only oils ,spills, fluids) won't be covered by this warranty.

Bolts & nuts

Bolts and nuts are warranted to be free from defects in material and workmanship for 1 year from item purchased. Damage from exposure to chemicals (including not only oils ,spills, fluids) won't be covered by this warranty.

Warranty Limitation

This warranty is for the original purchase order only. (Order number required). This warranty is non-transferable. Domi outdoor living is responsible for the free replacement part including shipping charges for the 1 year warranty.

Warranty Exclusion

This warranty does not cover products subject to negligence, abuse usage, inappropriate installation. Domi outdoor living reserves the right to explain warranty exclusions. When the replacement item is applied, the 1 year warranty automatically expires. Please feel free to contact us for applying warranty.