



Item: Recliner

SKU:N719P18747




PART LIST


A



B



C




C1

C2


back ears

D




arm pads

E




F




a




b




G










H



I









1



2


A

Pull hard




hold the handle of the arm and pull hard to make it stretch out, when you need fold it pull hard from the bottom and push the top at the same time




3



4




5




please put seat cushion to the center of seat correctly
and tight with Velcro

6






open the zipper

D





D



7




8




B








9









10




11





BLACK




12



-8-



13



14

