


Assembly Instructions



Before Assembly

Important Notes

Thank you for choosing our product.

Please read this section carefully before you begin assembly. Keep this booklet for future reference.

NOTICE

Package Check:

Before you begin, please take a moment to check that all parts are present and undamaged. We also suggest keeping the outer packaging until you've done so.

Returns:

Once opened, compressed cushions cannot be recompressed.

Returns are accepted only for items in original, unopened condition with the original packaging retained. If you wish to return the product, please use the return label provided by us. Do not return the product without prior authorization.

WARNING



Small parts and plastic packaging materials are included. Keep all hardware, tiny components, and protective bags out of reach of babies, children, and pets during and after assembly to prevent accidental swallowing or suffocation.

CAUTION

Assembly Safety & Tips:

- Due to the weight and size of the sofa components, we strongly recommend that at least 2 adults work together to complete the assembly to avoid personal injury or product damage.
- Assemble the product on a clean, scratch-free, flat surface (such as a carpet or the cardboard shipping box) to prevent damaging your floors or scuffing the fabric.
- Follow all assembly steps in order.
- Do not fully tighten screws immediately. Secure all screws to about 80% first, then perform final tightening once all parts are aligned.

Need Help?

Contact our support team if you experience any of the following:

- Outer box is damaged.
- Product is damaged, bent, or cracked upon opening.
- Parts, accessories, or assembly tools are missing.
- Instructions are unclear.
- Product has functional problems.
- Any other issue you are not satisfied with.

Carton 1

Ensure all parts are present and undamaged before starting. We recommend keeping the outer packaging until you have confirmed that all parts are present and undamaged.


Part

A Wooden Slat




1x

B Seat Cushion



3x

C Iron Back Frame




2x

D Back Cushion



3x

G Seat Cushion Cover



3x

H Back Cushion Cover



3x

J Leg



4x

K Seat Frame Plate (Front)




2x

L Seat Frame Plate (Back)




2x

M L-shaped Iron Piece




4x

S Connecting Iron Piece




2x

I Back Frame Connecting Piece



2x

T Seat Frame Connection Piece




1x

U Back Frame Cover



1x

V Seat Frame Cover



1x

W Leg (middle)




2x

N Gasket



6x

O Washer




34x

P Screw
M8*20




28x

Q Screw
M8*60



4x

X Screw
M8*80




1x

Y Butterfly Nut



1x

R Allen Key




1x

Carton 2


Part

E Left Armrest



1x


F Right Armrest



1x

Installation Steps

STEP-1 Connect the front and rear plates of the seat frame, and assemble part M (L-shaped Iron Piece) onto part K and part L (seat frame plate).




Align the elliptical hole with the seat frame plate.


 P x 12

 O x 12


STEP-2 Put part V (seat frame cover) onto the front panel of part K (seat frame).
Note that there are gaps on both sides, and the upper side should be pasted upwards




STEP-3 Use part T (Seat Frame Connection Piece) to connect the front and rear seat frame plates with iron.




STEP-4 Assemble part E (Left Armrest) and part F (Right Armrest).




The handrail does not need to be locked for the time being, otherwise the iron back frame behind it is inconvenient to install.




STEP-5 Assemble part J (leg) and part W (middle leg).




STEP-6 Assemble part C (iron back frame) .




STEP-7 Cover the iron back frame with part U (Back frame cover).



STEP-8 The Velcro at the bottom of part A (wooden slats) adheres to the Velcro on the seat frame.



STEP-9 Fix the armrest to the iron back frame.





Lock the iron back frame and then lock the armrest.


 Q x 4

 O x 4


STEP-10 Unpack the compression pack and put it into the corresponding cloth cover to fully fill within 72 hours.



STEP-11 Place part B1 and part D1 in the corresponding pockets.



COMPLETE



After Assembly

User Tips & Support

Frequently Asked Questions

1. What should I do if my shipment is damaged or the product is defective?

We are sorry for any inconvenience. Please contact us promptly and follow these steps:
Keep the original box (in case a return is needed).

Take photos of the damaged box, the damaged part(s) and the tracking number.

Send the photos to us so we can process a replacement or refund.

2. What should I do if a compressed product does not return to its original shape?

For safety during shipping, some products or cushions are packaged in a compressed form. We recommend allowing some time for the product to expand. Gently patting or fluffing the cushion can help speed up the process. If the issue persists, please contact our customer support team.

3. Return & Warranty Information

Returns:

If you are not satisfied with your purchase, you may initiate a return within **30 days** of receiving the product. Simply message us with your reason, and we will help facilitate the process. Please note that returns are accepted only for items in original, unopened condition with the original packaging retained.

All returns must use our provided return label and require prior authorization. Do not return the product without it.

Warranty:

We offer a 1-year manufacturer limited warranty for this upholstered sofa, effective from the date you receive your order.

During the warranty term, if any structural parts, hardware or original accessories arrive damaged or fail under normal household use, we will ship brand new replacement components completely free of charge with no extra cost.

Warranty Exclusions:

This warranty does not cover:

- Accidental damage, improper use, abuse, or man-made destruction;
- Normal wear and tear, stains, scratches, fading, and fabric aging over time;
- Damage caused by outdoor use, commercial use, or extreme environments;
- Unauthorized modification, disassembly, or self-repair of the product;
- Damage from improper installation, overloading, or pet damage.

Daily Care Instructions:

With proper care, your furniture will last for years. Please follow these guidelines:

- Keep the sofa away from direct sunlight, or use curtains/blinds to reduce exposure.
- Clean regularly with a dry, soft cloth or a vacuum with a soft attachment.
- For stubborn stains, gently blot with a soft cloth dipped in warm water and mild soap, then dry with a clean cloth.
- Avoid excessive rubbing, as it may damage the weave or cause discoloration.
- Place felt pads under the sofa to prevent floor scratches. A rug underneath also adds protection and style.
- Distribute weight evenly on the cushions over time for optimal care.
- When moving the furniture, always lift it rather than dragging it across the floor. Dragging can damage legs, joints, and flooring.
- Keep sharp objects away from the fabric or leather surface to prevent snags, tears, or scratches.

NOTICE

PERIODIC STRUCTURAL CHECK:

Daily use can cause connection joints to loosen over time. For long-term stability and safety, periodically check and retighten all bolts, screws, and hardware connectors every 3 to 6 months.

WARNING

PROHIBITED MISUSE:

Do not stand, jump, or sit on the armrests or backrest of this sofa. The product is designed for sitting purposes only. Improper use may cause the furniture to tip over, break, or result in personal injury.

NO POWER TOOLS:

Do not use high-torque power drills to assemble this product. Power tools can easily strip the hardware threads, split the inner wooden frame, or tear the fabric. Use the provided hand tools only.

Thank you for choosing us. We look forward to welcoming you back soon!