

INSTALLATION STEPS

1



2



3



4



5



6



⚠ There are two shims, which the customer should adjust and install according to the unevenness of the chair.