

Hardware :

8 -- 3 cm Screws	1 -- Table Top
8 -- Washers	1 -- Harp Leg Assembly
8 -- Lock Washers	4 -- Feet
1 -- Allen Key	1 -- Base

Assembly Instructions :

1. Put (1) lock washer and then (1) washer on each screw.
2. Lay Table Top upside down on clean surface.
3. Line up holes in top of Harp Leg Assembly with inserts on bottom of Table Top. Attach using (4) 3 cm screws. Tighten with Allen Key.
4. Align holes in Base with inserts in bottom of Harp Leg Assembly. Attach using (4) 3 cm screws. Tighten with Allen Key.
5. Insert screws on Feet into inserts on bottom of Base. Finger tighten.