

■ Specification

Voltage: 110-130V

Wattage: 40Watt Max X 3

Material: Metal+Wood+Fabric

Lamp holder: E12 X 3

Bulb info: E12 5W LED 3000K

Item Weight : 2.2KGS/ 4.8LBS

Dimensions: 14.5in/368mm(W)*60in/1525mm(H)

Shade size: 12.8in/325mm(D)*49.5in/1258mm(H)

Base size: 14.5in/368mm(W)*10.5in/267mm(H)

Wire Length: 59in/1500mm

Usage: Indoor use only

■ Package Includes

3 x Wood leg

1 x Metal wire frame

1 x Top ring

4 x Tube

1 x Finial

1 x Butterfly nut

3 x Allen Screw

1 x Allen wrench


1 x Lamp shade

3 x E12 type B 4W LED bulb

1 x User Manual

■ Easy Installation

1. Place the three wood legs (A) into metal wire frame (B), and secure them using allen screws (C) and allen wrench (D). (As the drawing shown)
2. Screw tube (E) onto tube (F).
3. Screw tube (F) onto tube (G).
4. Screw tube (G) onto tube (H).
5. Insert tube (H) into metal wire frame (B), secure them with the butterfly nut (K).
6. Place the metal top ring (L) onto tube (E), and secure it with finial (M).
7. Install the bulbs (N) into the sockets (I). (Bulbs included)
8. Place the shade (P) over metal Top ring (L).
9. Attach the bottom of shade (P) to metal wire frame (B) to steady the lamp shade. Lamp assembly is completed.



■ Attention

1. Recommend to use LED bulb, If you want to use incandescent bulbs, less than 40W are greatly recommended.
2. The bulb will increase the brightness when it is reaching its lifespan or has partial short-circuit. At that moment, please switch off, change a bulb and use it as you would normally.
3. Please shut off the power and unplug it before you screw in a new bulb.
4. Don't put the lamp in overheating working condition or cast it into fire.

