

GLIDER MOTION LOVESEAT WITH  
CONSOLE WITH DRAWER (WITH USB FUNCTION)  
ASSEMBLY INSTRUCTION



# Assembly Instruction


## ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast& easy assembly.



## Warning !

- 1.Do not attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME PER UNIT:

5 MINUTES


## PARTS IDENTIFICATION

- (A)  RIGHT BACK 1PC
- (B)  LEFT BACK 1PC
- (C)  CONSOLE BACK 1PC
- (D)  BASE 1PC
- (E)  LEFT EAR 1PC
- (F)  RIGHT EAR 1PC


## ASSEMBLY INSTRUCTION

IT NEEDS TWO PERSONS AND TAKES ABOUT FOUR MINUTES TO ASSEMBLE THE ITEM


### STEP 1



### STEP 2



### STEP 3



ASSEMBLY TIME PER UNIT:

5 MINUTES

