




INSTALLATION INSTRUCTIONS
SWING ARM SCONCE

Thank you for purchasing from Barn Light Electric, America's leading manufacturer of hand-crafted shades and exclusive source for porcelain enamel lighting! For questions or concerns about your purchase, please contact us!


INS-0073 REV C (HWK-0101)

ALTERNATE FIXTURES

These alternative shades follow the same installation instructions as the illustration shown below.



The Fluted Shade
Swing Arm Sconce



The Circle B
Swing Arm Sconce

IMPORTANT

Read all instructions before assembly. Installation is to be done by a qualified professional.

CAUTION: Risk of fire, this product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

CAUTION: Do not apply excessive downward or upward force when positioning the swing arm on the light fixture.

INSTRUCTIONS

1. Temporarily set fixture Backing Plate (A) level and plumb against the wall to mark the two hole locations for mounting.
2. Drill two holes using 1/4" drill bit and insert plastic Anchors (B) until flush against mounting surface.
3. Align fixture with the two wall Anchors (B) and install Mounting Screws (C).
4. Tighten until fixture is flush and secure against wall. Do not over tighten screws.
5. Remove Stem Cap (D) from the end of the Stem (E).
6. Set desired Cord (F) length. Insert Cord (F) into the Stem Slot (G) nearest to the wall.
7. Thread Stem (E) into swivel on wall Backing Plate (A). Tighten Set Screw (H) to lock into place.
8. Wrap cord/fixture around Stem (E). Insert Cord (F) into the Stem Slot (I) at the end of the Stem (E).
9. Set desired height of the fixture and thread the Stem Cap (D) onto end of Stem (E) to secure cord in place. **NOTE: Do not over tighten as it may pinch the cord.**

SWING ARM SCONCE

- A. Backing Plate
- B. Anchors
- C. Mounting Screws
- D. Stem Cap
- E. Stem
- F. Cord
- G. Stem Slot
- H. Set Screw
- I. Stem Slot

