


PATIO DINING TABLE








Instruction Manual



- Excellent weather resistance
- Easy to clean and maintain



Instruction Manual

ASSEMBLY PARTS

A		B			
Left Table Panel: 1 pc		Right Table Panel: 1 pc			
C		D			
Legs: 4 pcs		Leg Support Tube: 2 pcs			
E		①			
Connecting Tube: 2 pcs		Allen Wrench: 1 pc			
②		③		④	
M6*15 Screw: 16 pcs		M6*35 Screw: 16 pcs		M6*65 Screw: 2 pcs	
⑤		⑥		⑦	
Washer: 4 pcs		Nut: 2 pcs		Wrench: 1 pc	



Step 1

Insert the connecting tube (E) into the left table panel (A) and align the holes. Then insert the M6*15 screws (②) and tighten them with the allen wrench(①)





Step 2

Insert the right table panel(B) to cover the connecting tube and align the holes. Then insert the M6*15 screws (②) and tighten them with the allen wrench(①)





Step 3

Place the washers(⑤) on both sides of the pipe, insert the M6*65screws (④) and cover the nuts(⑥) on the other side, and then tighten with the allen wrench(①) and wrench(⑦)





Step 4

Insert the legs (C) into the table panel and align the holes, Then insert the M6*35 screws(③) first, and then tighten the screws with the allen wrench(①) until they are tight



Step 5

Place the leg support tube(D) between the legs and align the holes. Then insert the M6*15 screws(②) tighten the screws by allen wrench(①) to make the table more stable



Set the patio dining table upright.

PAY ATTENTION

DO NOT EXCEED THE MAXIMUM LOAD OF 330LBS.



DONE!

WARRANTY

Patio Dining Table

3-year basic Warranty Program

► We offers a 3-year basic warranty on the entire table from the date of purchase against defects in material and workmanship. During this period we will repair and replace, at our discretion, the defective component.

► This warranty does not apply to improperly installed, handled, abused, damaged by user error, nor to any unit which has been repaired or altered by unauthorized repair companies.

Under no circumstances will the customer entitled warranty to

► consequential or incidental damages. This limited 3-year basic warranty will only grant customers certain legal rights; customers may have other rights according to different state laws.

HOW TO CONTACT US

Step 1:
Log in to your
account.

Step 2:
Go to Your Orders.
Select the item you
purchased from us.

Step 3:
Select Contact seller.

