INSTRUCTION MANUAL

Item: SR2526SW-SOL



Outdoorfountain@outlook.com

772-203-6390

Support Hours: 7:30 – 5:00 (U.S. Pacific Time)

Version - V 2.0

Contents

- Package Included 1
- Replacement and Water Pump 2
- Assembly Instructions 3
- Troubleshooting and Solutions 5
- Warranty & Return Policy 6
- Maintenance & Care 6

Package Included



01 Water Fountain



02 Fountain Back Panel



03 Solar Water Pump



04 USB Charging Cable




05 Gardening Glove



06 1 Pound Pebbles



07 Solar Panel



08 KD Part

**The water pump and transformer are housed in the same small box.*

Replacement and Water Pump

REPLACEMENT PART

No.	Model	Model No.	Picture
1	Solar Pump	P003G6-2PIN Pump	
2	Solar Panel	P003G6-2PIN Panel	
3	LED Lights	SR2526SW-SOL LED Sets	

WATER PUMP PARAMETERS

Solar Panel	5W-5V
Operation Voltage	6V DC
Qmax	340LPH
Hmax	1.05M
Cable Length	5M
Lithium Battery	3.7V-4000mAH

HOW TO ADJUST THE FLOW

- Always isolate the electrical mains supply before touching or adjusting the pump.
- The pump flow can be adjusted with the regulator, this is found on the inlet of the pump.
- Adjustments up to 30%. Turn clockwise for full flow / anti-clock-wise for reduced flow.

Assembly Instructions

1



Wear protective gloves. Place the “KD Part” into the top recessed slot, let the water hose to straight down to the bottom of the fountain. Take the water hose and LED cable from the fountain.

2



Connect the shorter cable to the LED light cable and tighten the nut. The pump's long power cord exits through a hole from the inside out. Attach the longer pump cable to the solar panel and tighten the nut securely.

3



Connect the fountain hose to the pump, place the pump inside the fountain.

4



Add water through the fountain inlet until the water level is about 2 inches above the pump.

5



Organize the cables. Cover the cable outlet with a sealing plug.

6



Assemble the solar panel, place the panel at a 20-30 degree angle for charging. Press the solar button switch to start.

7



Add decorative pebbles. Place pebbles on each tier of the fountain as desired, taking care not to block the water return outlets.

* Place the fountain base on a smooth level surface.

* When first using the fountain, air may be trapped in the pump. It may take a few minutes for the water to flow smoothly.

Scan QR Code
to see install video

https://youtube.com/shorts/uyp6UdzJy3k?feature=share

Troubleshooting and Solutions

Trouble	Solutions
Pump not working	● Make sure the pump is fully submerged, with at least 2 inches of water above it. ● Check that the flow control valve is fully open. ● Clean the pump impeller and intake to remove any debris or blockage. ● Check all power connections, including the outlet, transformer, and pump plug.
If the pump makes unusual noise Scan QR code for the pump disassembly video https://youtube.com/shorts/yMHcq_kYIaY	● Turn off and unplug the power supply. ● Remove the front cover of Pump. ● Carefully hold and remove the impeller/rotor assembly. ● Rinse the impeller assembly with clean water and clean the pump chamber. ● If any damage is found, contact your local dealer to replace the part.
Low water flow	● Add water to prevent low water level. ● The pump or tubing may be blocked. Clean the pump and tubing. ● The flow control may be set too low. Turn counterclockwise to increase water flow. The default setting is maximum.
LED Lights not work	● Check transformer connection is tight and secure. ● Reconnect the dual-pin interface, ensuring the interface is dry. ● If none of the lights illuminate, it may indicate a transformer malfunction. ● If only some LEDs are out, they may be faulty.
If the lights are flickering	● Often caused by algae or mineral scale on LED contacts. ● Clean pump and fountain.
White/Green Residue	● Mineral buildup (limescale) or algae growth may occur. This is not a device malfunction. Please clean the fountain and pump regularly. Using distilled water can help minimize limescale buildup.
Water Leakage	● Place the fountain on a flat, level surface. ● Do not overfill the basin. ● Natural evaporation will occur; refill with water as needed. ● If water leaks from a seam, apply a waterproof sealant to repair it and contact us for compensation. ● If the fountain is damaged, please contact us for a replacement.

**If you have further product questions, feel free to reach out.*

Warranty & Return Policy

01 / RETURN POLICY

- Returns within one month of purchase date: Free return service provided
- Returns after one month: Buyer responsible for return shipping cost
- Non-quality issue returns: Buyer responsible for half of the shipping costs
- Purchase within one month, if you find a lower price, don't need to return and please contact to get reimbursed for the difference.
- Please return the product via the Amazon label or the label provided by the seller.

02 / WARRANTY TERMS

- 30-Day Free Return policy. 1-Year warranty for non-artificial damage.

03 / NOT COVERED UNDER WARRANTY

- Pump smells of burning residue.
- Discoloration resembling rust.
- Visible algae or limescale buildup on the pump.
- Paint and/or surface damage/discoloration due to limescale.If any of the above is noticeable, the warranty will void due to likely improper maintenance.
- If the proof of purchase shows the product was bought within 1 Year, free charge replacement part can be supplied.

Maintenance & Care

Fountain Care Guidelines

- Winter Care: Bring Indoors if Possible (e.g., garage or shed). If freezing is a concern, drain all water to prevent damage.

Fountain Cleaning Tips

- To empty the fountain of water for cleaning or for winter care:
- For smaller fountains, invert and let water pour away forcleaning.
- For larger fountains, use siphon pipe for water removal. Always power off before cleaning or maintaining thefountain or pump.

Note: Stains may be present, this does not imply the fountain is second-hand. The testing water may not dry beforerepacking, causing stains upon opening the package.