

HOW IT WORKS

TableBed | ASSEMBLY MANUAL

HOW IT WORKS

HOW IT MOVES UP AND DOWN:

The mechanism that allows the TableBed to move up and down is spring-loaded and located inside the FootRest.

As the TableBed is lowered down, gravity is naturally starting to pull it down. The springs “kick in” and provide enough resistance to avoid it from coming down too quickly.

As the TableBed is raised upward, gravity is resisting. To make it easier to lift, the

springs release tension, assisting the bed as it is raised.

TO LOWER THE TABLEBED:

Handles are located on the outside of the Bed Cabinet (on the Bed Panels) for use to lower the Bed.

TO RAISE THE TABLEBED:

At the corner of the bed platform, place hands underneath and lift. Start walking toward the bed cabinet to close. Once at half-way, grab a handle and guide into the cabinet.

HOW IT WORKS (CONT.)

HOW TO ADJUST TENSION:

To adjust the tension of the TableBed:

Locate the two Bolts underneath the FootRest.

The ideal adjustment is to have as much tension as possible, so the bed is easy to raise and lower, but not so much that it “floats” up after it is lowered.

STEPS FOR ADJUSTMENT:

1. Place TableBed in Up Position
(so there is no tension when you are working)
2. Loosen the two 3/8” Bolts under the FootRest
3. To INCREASE tension: slide the bolts toward the TableLeg (away from TableBed) and tighten.
4. To DECREASE tension: slide the bolts away from the TableLeg (toward the TableBed) and tighten.

TROUBLESHOOTING

TableBed | ASSEMBLY MANUAL

TROUBLESHOOTING

HOW CAN I ACCESS BEHIND THE TABLEBED?

If you need to access to the area behind the bed, you most likely do not have to remove it from the wall. The Headboard does release, allowing access behind the Bed.

TO LOWER THE HEADBOARD:

Have someone lower the bed about halfway and hold it there. On the back of the Headboard there are guide pins located on the left and right, with a cable stretched between them. These pins extend into the track located on each side of the cabinet,

guiding the Headboard movement as the bed is raised and lowered. Reach behind the Headboard and locate the cable. Pull the cable upward to release the pins on both side and pivot the Headboard forward to the mattress. Make sure you keep holding tension on the cable as you pivot the Headboard to prevent the pins from scratching the inner faces of the Cabinet Sides. At this point, the Bed can be lowered down completely. To re-engage the pins, pull upward on the tension cable and raise Headboard, until the pins are aligned with the track. Release the cable. The pins

should snap out into position, resetting the headboard for use.

REMOVING BED FROM WALL:

With another person, “walk” each side of the Cabinet away from wall.

TIP: You may want to place moving pads underneath cabinet (with another person, tip cabinet slightly to place pad).

MY TABLEBED IS MAKING A SQUEAKY NOISE

First, confirm bolts underneath FootRest are tight and in the desired location

TROUBLESHOOTING (CONT.)

(See: How It Works - Adjustment). **Test.**

The TableBed has 5 sets of Hinges that require periodic lubrication - see Care & Maintenance

THERE IS A LOUD BANG OR GUITAR STRING NOISE

This noise is most likely coming from the springs located in the FootRest.

If the TableBed is moving freely, cycle it up and down 3-5 times to see if this corrects itself. **Test.**

If the TableBed does not move freely or this does not resolve the issue, Contact Us to further troubleshoot.

CARE & MAINTENANCE INFORMATION

Please refer to your Welcome Booklet for detailed information on Care & Maintenance

NEED TO DISASSEMBLE AND MOVE THE TABLEBED

Reverse assembly steps from manual

TIP: Bag and label hardware per Step. This will be very helpful when reassembling the TableBed.

I HAVE A BROKEN PART THAT NEEDS TO BE REPLACED

Please call Wayfair with your order ready.

THE TABLEBED IS DIFFICULT TO BRING DOWN (OPEN)

IMPORTANT!: Never Force Bed Open

First, confirm bolts underneath FootRest are tight and in the desired location (See: How It Works - Adjustment). **Test.**

TROUBLESHOOTING (CONT.)

If it still will not open, access behind the TableBed (see above)

With a flashlight, look closely for any object (may be small) that may be obstructing the mechanism from working properly.

Also check that all connections are still in tact (see assembly manual for proper installation). Prior to moving Bed back in place, **Test.**

THE TABLEBED IS DIFFICULT TO RAISE UP (CLOSE)

IMPORTANT!: Never Force TableBed Closed

First, confirm bolts underneath FootRest are

tight and in the desired location (See: How It Works - Adjustment). **Test.**

Remove any pillows. **Test.**

Confirm mattress and bedding has not exceeded maximum thickness (see original order for maximum thickness allowed). **Test.**

If the TableBed still will not raise up, lower the Headboard (see instructions under Access Behind Bed) and with a flashlight, check for an object (may be small) that may be obstructing the mechanism from working properly. Remove object. Also confirm all

connections are still in tact with mechanism (see assembly manual for proper installation). Set HeadBoard back in place. **Test.**

If the TableBed still will not raise up, confirm bolts underneath FootRest are tight and in the desired location (See: How It Works - Adjustment). **Test.**

FEEDBACK WELCOME

FEEDBACK WELCOME:

This assembly manual was created with you in mind. Over the years, we have been asked common questions and received important feedback on our products and services.

With great care, and through continuous improvement and learning, we have incorporated the answers and feedback within these manuals. We hope you find them useful and easy to use!

With this said, if there is any outstanding question that you have, please do not hesitate to contact us.

We also welcome any and all feedback about our product and your experience with it. Email or call us.

We hope you enjoy your TableBed for many years to come!

THANK YOU.