


ASSEMBLY INSTRUCTION










Any problems, we are here for help.








■ Patio Furniture Set

THANK YOU
FOR YOUR PURCHASE. YOUR SATISFACTION IS OUR RELENTLESS PURSUIT!

3-SEAT SOFA


Check and ensure you get the components on the list, contact us for any missing.

PARTS LIST		
A		1PC
B		1PC
C		1PC
D		1PC
E		1PC
F		1PC
G		3PCS


HARDWARE LIST		
R	 M6*40	10PCS
S	 M6*30	4PCS
T	 M6*50	4PCS
U	 M6*70	2PCS
V		16PCS
W		1PC
X		4PCS

NOTE: Do not tighten bolts until all parts are connected.
Washers must be used.


Step 1




Step 2




Step 3



Step 4










Completed Unit



OTTOMAM


Check and ensure you get the components on the list, contact us for any missing.

PARTS LIST		
H		1PC
J		2PCS
K		2PCS
L		1PC


HARDWARE LIST		
S	 M6*30	14PCS
V		14PCS
W		1PC

NOTE: Do not tighten bolts until all parts are connected.
Washers must be used.


Step 1




Step 2




Step 3



Step 4











Completed Unit



COFFEE TABLE

Check and ensure you get the components on the list, contact us for any missing.



PARTS LIST		
M		1PC
N		1PC
P		1PC
Q		1PC

HARDWARE LIST			
Y		M6*15	4PCS
R		M6*40	8PCS
V			12PCS
W			1PC


NOTE: Do not tighten bolts until all parts are connected.
Washers must be used.

Step 1

Step 2




Step 3




Completed Unit



NOTE: Do not sit on the table.



Patio Furniture Clips


Preventing sofa from moving.
Used to fix the bottom of the sectional sofa.

PARTS LIST		
Z		2PCS





Any problems, Contact us! We are here to help!

FIX CUSHION BY BUCKLE




Cushion



HELP CENTER



Questions about your product? We are here to help.



■ Please provide **ITEM#** on the first page of the assembly instruction.

NOTICE

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and knobs before use.
- Reconfirm that all bolts, screw, and knobs are secure every 90 days.
- Do not use or store this item in the proximity of open or flame or flammable/combustible chemicals.
- Cover furniture for long-lasting use when left outside during inclement weather or when not in use for long time.
- Never wrap cushions in plastic for storage to prevent mildew.
- Make sure the unit is completely dry before storage.

WARRANTY PROGRAM

- Return accept for up to 30 days from the date of original delivery.
 - Item returned must be in their original packaging or acceptable packing, along with all accessories in the original shipment.
 - 1-year warranty for the date of original delivery against manufacturer defects under normal use and conditions. Residential use only.
-