

INSTRUCTIONS FOR INSTALLING YOUR WESLOCK PRODUCT

Mansion/ Philbrook/Woodward/
Belmont Dummy-Entry Handle



PARTS INCLUDED


Do not insert key, or unlock handle before installation. Doing so may result in removal of the cylinder assembly.

Exterior Grip Assembly

Exterior handle & thumb piece.



Interior Mounting Plate



Foot Screw Cap Assembly



* Only use one (1-3/4") screw based on thickness of door.


Interior Escutchen Screw (X2)




For mounting interior deadbolt assembly.

Interior Lever/ Knob Assembly
Reversible

Interior knob /lever, rosette& spindle



Exterior Deadbolt Assembly



Assembly Screws (x4)

Pre-installed on Exterior Grip Assembly for mounting interior knob / lever assembly (1")




For mounting interior deadbolt assembly. (1-2/5")

REQUIRED TOOLS


Measuring Tape

Or other measuring tool




Screwdriver

Phillips and flat blade




Wood Chisel

*Only if prepping a new door




Allen Wrench



Writing Utensil

*Only if prepping a new door



DOOR PREP INSTRUCTIONS 2 WESLOCK.COM

GLOSSARY OF TERMS

Technical language used in this document



MORTISE



CROSS BORE



EDGE BORE



THUMB PRESS LATCH




DEADBOLT LATCH


INSTALLATION

*Dummy Entry Handle Requires Cross bore and foot screw holes to be bored out before installation

7A. Install exterior assembly into crossbore and footscrew holes. Slide dummy deadbolt cylinder into deadbolt hole after exterior handle has been installed



7B. Install interior Mounting Plate with the 4 mounting screws and then install interior plate with the 2 escutcheon screws provided. * Note make sure the deadbolt is in the locked position with thumb turn pointing to the edge of the door for the lock to function properly.



* Knobs and Levers are attached with set screws. Remove and attach knobs and levers with the Allen wrench provided.

THANKS FOR CHOOSING US. WE HOPE YOU ENJOY YOUR NEW WESLOCK DOOR HANDLE.

WESLOCK WARRANTY INFORMATION

WESLOCK warrants to the purchaser that the products shall be free from defects in material workmanship for the LIFETIME of the product. Provided the product was purchased from an authorized WESLOCK dealer, Weslock's sole obligation under this warranty shall be to repair or replace product which WESLOCK determines to be defective. After such product is returned to WESLOCK by the purchaser with proof of purchase and with shipping charges prepaid, will this warranty be honored. Homeowner - if the product was installed as original equipment on a new home, you must provide the name of the builder, the date the home was built and your move-in date. If a mechanical defect has occurred, it is your right by this warranty to contact Customer Service in Tulsa, Oklahoma at (800) 575-2658 to arrange the return of the lock. This warranty DOES NOT cover products which malfunction due to improper installation or misuse. **Please register your product at Weslock.com.**

WARRANTY TERMS

FINISH

MECHANICAL

Elegance Collection

Limited Lifetime

Limited Lifetime

ADDITIONAL CUSTOMER RESOURCES

Online

WEBSITE

For our full product catalog, and video instructions, go to;

www.weslock.com

TWITTER

To learn about promotions, and other news, follow us at;

twitter.com/Weslock1

YOUTUBE

Browse our video library, or leave us comments at;

youtube.com/WeslockDoorHardware

FACEBOOK

See what we're up to, or ask us a question at;

facebook.com/WeslockDoorHardware

Direct

PHONE NUMBER

1-800-575-2658
B O L T

FAX NUMBER

1-918-294-3869

EMAIL

customerservice@weslock.com
or
warranty@weslock.com

TEMPLATE

