

















# ASSEMBLY INSTRUCTIONS

## DINING CHAIR


**Thank you for purchasing this quality product. Be sure to check all packing material care fully for small parts, which may have come loose inside the carton during shipment. Identify and count all parts and compare with the **HARDWARE LIST** below.**

NO.	DESCRIPTION	SKETCH	QTY
A	Chair Back		1PC
B	Seat Frame		1PC
C	Left Front Leg		1PC
D	Right Front Leg		1PC
E	Left Side Stretcher		1PC
F	Right Side Stretcher		1PC
G	Front Side Stretcher		1PC
H	Cushion		1PC


NO.	HARDWARE LIST		QTY
1		Bolt (Ø1/4"x75mm)	4Pcs
2		Bolt (Ø1/4"x60mm)	4Pcs
3		Bolt (Ø1/4"x40mm)	2Pcs
4		Flat Washer (Ø1/4"x19x2mm)	10Pcs
5		Spring Washer (Ø1/4x11x2mm)	10Pcs
6		Allen Wrench 4mm	1PC
7		Wood Screw (Ø4x40mm)	6Pcs




STEP 1




STEP 2



STEP 3



STEP 4



STEP 5

Note: Please DO NOT fully tighten all screws and bolts until the entire item is completely assembled