


Assembly Instructions for Model HL220861186

Package Contents

| Part | Description | Quantity |
|------|-------------------|----------|
| A | Arm Support Plate | 1 pc. |
| B | Glass Shade | 4 pcs. |
| C | Mounting Bracket | 1 pc. |
| D | Fixture Arm | 4 pcs. |
| E | Ceiling Canopy | 1 pc. |



(Please watch the video for specific details.)

STEP 1

Connect the Fixture Arm (D) to the Arm Support Plate (A) .



STEP 2

Thread the electrical wire through the Arm Support Plate (A) .

Twist together wires of the same color.

Connect the Fixture Arm (D) 's wire to the electrical wire.



Note: Split the electrical wire into two strands and connect each strand to the other two wires separately.

STEP 3

Thread the electrical wire through the Ceiling Canopy (E) .

Secure the Ceiling Canopy (E) to the Arm Support Plate (A) .

STEP 4

Mark the drilling position on ceiling with the help of the Mounting Bracket(C).

Drill holes on the marks and stick the hook-shaped expansion anchors into the holes.

Fix the Mounting Bracket(C) to the hook-shaped expansion anchors with self-tapping screws.

STEP 5

Hold the fixture close to ceiling.

Connect live line to wire color Black/Red from the Fixture.

Connect neutral line to wire color White/Blue from the Fixture.

STEP 6

Attach the Ceiling Canopy(E) to the Mounting Bracket(C).

STEP 7

Fix the Glass Shade(B).

Your fixture is now assembled and ready to use.