


# ASSEMBLY INSTRUCTION

## MIRROR

**A**


Mirror




1 pc

**B**


Back Support



2 pcs

**C**CSK Screw  
M4 X 32mm

10 pcs



Mirror


Dresser

This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


**IMPORTANT NOTE :**

1. Do not tighten all screws / bolts until all completely assemble.
2. Keep all hardware parts out of reach of children.

- 1** Place the Mirror Back Support (B) to the back panel of Mirror as shown and secure it with CSK Screw (C) using Phillip Head Screwdriver ( Not included)



- 2** Align the Marking Line with the Mirror Back Support (B) at back of Dresser (as shown) and secure it with CSK Screw (C) using Phillip Head Screwdriver ( Not included)



#### **CLEANING & CARE**

Treat surface with care. Surface is resistant to scratches but is not scratches resistant. Clean surface with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen overtime. Periodically check that all connections are tight.