

## Installation Notes







## Fan lamp remote control instructions

Remote control key function:

(U):Main switch

:Light switch

:Natural wind

😘 :Fan off

😂 :Fan gear key Gear 1-6 Forward

F:rotation


R:reversal

(1H):Fixed time 1 hour

②H:Fixed time 2 hours+pair key

Fixed time 4 hours

Remote control battery: No. 7 1.5V\*2



## Product introduction:

1. This product adopts 433 wireless digital technology,

Remote control one-to-one control,

The workpiece can be controlled from any angle within the allowable space,

Not limited by direction, Simple and convenient operation,

Strong anti-interference ability.

- 2. Remote control instructions:
- ① . If the remote control is not used for a long time , Please remove the battery.
- ② . Remote control matching code :

Turn on the power,

Press the pair code button within 5 seconds of the light on,

When you hear two "tick" sound or the light flashes, the code matches successfully.

If you need to match the code again , You need to wait 30 seconds before turning on the power and repeat the above operation.

## warning:

This electronic switch product needs to be operated by professionals during installation.

Remote trigger electronic switch,

The radio frequency of the remote control transmitter is 433M

